

MU-A200/A400

SERVICE MANUAL

AEP Model



MU-A200



MU-A400

SPECIFICATIONS

Channel 2 channels
Input sensitivity 0dBs (100W +100W, 8 ohm load impedance, both channels driven simultaneously)

Input	Balanced	Unbalanced
Circuit	Electronic balanced circuit	
Input impedance	More than 33 kilo-ohms (stereo operation) More than 33 kilo-ohms (monaural operation)	
Connector and jack	XLR-3-31 type	XLR-3-31 type Phono type

Item	Stereo	Monaural (BTL)
Output terminal	Screw type binding terminal	
Rated output*	MU-A400	
	260 W + 260 W (8 ohms)	520 W (16 ohms)
	400 W + 400 W (4 ohms)	800 W (8 ohms)
	(both channels driven simultaneously)	
	MU-A200	
	130 W + 130 W (8 ohms)	260 W (16 ohms)
	200 W + 200 W (4 ohms)	400 W (8 ohms)
	(both channels driven simultaneously)	
Power bandwidth	20 Hz - 20 kHz $\pm$ 0.5 dB	
Damping factor	More than 150 (8 ohms, 1kHz)	—
Harmonic distortion	Less than 0.1 % (8 ohms, at 100 W output)	Less than 0.1 % (8 ohms, at 200 W output)
Channel separation	More than 70 dB (1kHz: 8 ohms load, at rated output)	—
Residual noise	Less than 100 μ V (IHF-A, input terminated)	Less than 200 μ V (IHF-A, input terminated)
Gain (max.)	31 dB	37 dB
Stacking output connector	XLR-3-32 type	

Indicator 10-point LED level meter
PROTECTION indicator
HIGH TEMP indicator
CLIP indicator
POWER indicator
Power requirements 220 - 240 V AC, 50/60 Hz
Power consumption MU-A400: 805 W
MU-A200: 425 W
Dimensions MU-A400:
Approx. 482 x 146 x 490 mm
(w/h/d)
(19 x 4 $\frac{3}{4}$ x 19 $\frac{3}{8}$ inches)
MU-A200:
Approx. 482 x 102 x 490 mm
(w/h/d)
(19 x 4 $\frac{1}{8}$ x 19 $\frac{3}{8}$ inches)
Weight MU-A400: Approx. 20.5 kg
(45 lbs 2 oz)
MU-A200: Approx. 15 kg
(33 lbs 2 oz)
Accessories supplied AC power cord (1)
Fuse MU-A400: 8A (1)
MU-A200: 4A (1)

Note

This appliance conforms with EEC Directive 87/308/EEC regarding interference suppression.

Design and specifications are subject to change without notice.

TECHNICAL DEPT. SEC.	
don't remove please	
S/M	LV
SE	LV
KEY	
SPEC	



MICROFILM

0 dBs = 0.775 V

*1 % harmonic distortion at 1kHz

PROFESSIONAL
POWER AMPLIFIER
SONY®

TABLE OF CONTENTS

Section	Title	Page
SPECIFICATIONS		1
1. GENERAL		
	Precautions	3
	Dimensions	3
	Location and Function of Controls	4
	Connection Examples	6
2. ADJUSTMENTS		7
3. DIAGRAMS		
	3-1. Block Diagram	8
	3-2. Circuit Board Location	8
	3-3. Semiconductor Lead Layouts	9
	3-4. Printed Wiring Boards – PRE AMP Section – (MU-A200/A400 : Identical)	11
	3-5. Schematic Diagram – PRE AMP Section – (MU-A200/A400 : Identical)	13
	3-6. Printed Wiring Boards – MAIN AMP Section – (MU-A200/A400 : Common)	16
	3-7. Schematic Diagram – MAIN AMP Section – (MU-A200)	19
	3-8. Printed Wiring Boards – MAIN AMP Section – (MU-A200/A400 : Common)	22
	3-9. Schematic Diagram – MAIN AMP Section – (MU-A400)	25
4. EXPLODED VIEWS		
	4-1. Outer External Section	28
	4-2. Main Section	29
	4-3. Front Panel Section	30
	4-4. Main Chassis Section	31
	4-5. Back Panel Section	32
5. ELECTRICAL PARTS LIST		33

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

NOTICE FOR THE CUSTOMERS IN THE UNITED KINGDOM THIS APPARATUS MUST BE EARTHED

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow: Earth

Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol $\perp$ or coloured green or green-and-yellow.

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.

The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK Δ OR DOTTED LINE WITH MARK Δ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE Δ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SECTION 1 GENERAL

This section is extracted from instruction manual.

Precautions

On Installation

Avoid installing or leaving the unit in a location:

- near heat sources such as radiators, airducts or heaters
- subject to direct sunlight
- exposed to rain or moisture
- where it is unventilated
- exposed to excess dust or dirt
- subject to mechanical vibration or shock


On Operation

- Operate the unit only on 220-240 V AC, 50/60 Hz.
- Unplug the unit from the wall outlet when it is not to be used for an extended period of time. To disconnect the cord, pull it out by grasping the plug. Never take out the plug by pulling on the cord.
- Should any solid object or liquid fall into the component, unplug the unit and have it checked by qualified personnel before using it again.
- Clean the cabinet, panel and knobs periodically using a soft cloth moistened with a mild detergent. Never use an abrasive cleanser or chemical solvents as they may mar the finish.

If you have any questions or problems concerning your unit that are not covered in this manual, please consult your nearest Sony dealer.

3


Dimensions



5

Location and Function of Controls

Front Panel



CHANNEL 1 and CHANNEL 2 have the same function.

- 1 CLIP indicator (red)**
Lights when the output wave is distorted. When the indicator lights frequently, the input level is too high or there is a problem in the input channel.
- 2 HIGH TEMP (temperature) indicator (red)**
Lights when the temperature of the heat sink becomes too high. Take a measure to be well ventilated.
- 3 PROTECTION indicator (red)**
Lights when the protection circuit is working. When you turn on the amplifier, the indicator lights but goes off when the unit starts to work steadily.
- 4 OPERATION indicator (green)**
Shows the operation mode set by the position of the OPERATION switch on the rear panel.

Position of the OPERATION switch	OPERATION Indicator		Operation mode
	CHANNEL 1	CHANNEL 2	
STEREO	Lights	Lights	Stereo
SAME OUT	Lights	Lights	CHANNEL 2 has the same signal as CHANNEL 1.
MONO	Lights	Out	Monaural through BTL

- 5 ATTENUATOR knob**
CHANNEL 1 (MONO): Turn this knob to control the channel 1 input level. You can control the input level with this knob when you are using the unit as a monaural amplifier through BTL.
CHANNEL 2: Turn this knob to control the channel 2 input level. When you set the OPERATION switch on the rear panel to MONO, this knob does not function.
- 6 Level meter**
The 10-point LED level meter shows 0dB at 8 ohms load, 100 W output.
- 7 POWER switch and pilot lamp (green)**
Press this switch to turn on the amplifier. The pilot lamp lights when the unit is turned on.

Note

When you set the OPERATION switch on the rear panel to SAME OUT, CHANNEL 1 and CHANNEL 2 are connected (stacking connection). You can control the channel 1 input level with the ATTENUATOR knob on the CHANNEL 1 side, and the channel 2 input level with the ATTENUATOR knob on the CHANNEL 2 side.

- 8 Ventilation hole**
Two ventilation holes with a fan are located on both sides of the front panel. The holes are covered with a grill and a cover. When the grills become dusty, the fans do not work properly and the HIGH TEMP indicator starts to light frequently. In this case, remove the ventilation hole cover and clean the grill. Unplug the AC power cord before cleaning the grill.

Caution

Do not touch the interior of the unit when you remove the grill.


Notes on the PROTECTION lamp

When does the PROTECTION lamp light?


The PROTECTION lamp lights when the protection circuit functions to protect the speakers and the amplifier by cutting off the output in the following cases:

- when DC (direct current) runs through the OUTPUT connectors because of a malfunction of the amplifier.
 - when the radiator located in the amplifier exceeds the normal temperature (the HIGH TEMP indicator lights continuously).
 - when the impedance of the speaker is too low, or when the output is terminated.
- In these cases, turn off the POWER switch, find the cause and resolve the problem. Then turn on the POWER switch to operate the amplifier.

To put back the grill and the cover




To remove the ventilation hole cover



Location and Function of Controls

Rear Panel



1 INPUT(MONO) and STACKING connectors

Connect outputs of a mixer or preamplifier. When you are using the unit as a stereo amplifier, these input connectors are for CHANNEL 1. When you set the OPERATION switch to SAME OUT or MONO, these connectors accept monaural input signals.

INPUT connector (XLR-3-31 type): Accepts balanced input when you set the BAL/UNBAL switch to BAL. When you set the switch to UNBAL, the connector accepts unbalanced input (Number 2: HOT).

INPUT jacks (phono type, unbalanced): Accept unbalanced signals when you set the BAL/UNBAL switch to UNBAL. Use one jack for input, another to connect another amplifier for stacking connection.

STACKING connector (XLR-3-32 type): Feeds out the signal which is received from the XLR type INPUT connector. Use this connector to connect another amplifier for stacking connection.

2 INPUT (Input 2) and STACKING connectors

Connect outputs of a mixer or preamplifier. When you are using the unit as a stereo amplifier, these input connectors are for CHANNEL 2. When you set the OPERATION switch to SAME OUT or MONO, these connectors are disconnected.


INPUT connector (XLR-3-31 type): Accepts balanced input when you set the BAL/UNBAL switch to BAL. When you set the switch to UNBAL, the connector accepts unbalanced input (Number 2: HOT).

INPUT jacks (phono type, unbalanced): Accept unbalanced signals when you set the BAL/UNBAL switch to UNBAL. Use one jack for input, another to connect another amplifier for stacking connection.

STACKING connector (XLR-3-32 type): Feeds out the signal which is received from the XLR type INPUT connector. Use this connector to connect another amplifier for stacking connection.

BAL/UNBAL switch	INPUT 1 (MONO)/INPUT 2 connectors
BAL	XLR type connector
UNBAL	Phono type jack

XLR-3-12C type



3 OPERATION switch

Changes the operation mode of the unit as follows.

OPERATION switch	Operation mode
STEREO	Stereo
SAME OUT	Internal stacking operation CHANNEL 2 has the same signal as the CHANNEL 1 input signal.
BTL	Monaural operation through BTL.

Select the position of this switch when the POWER switch is turned off.

4 OUTPUT terminals

Connect speakers. Connect the + speaker terminal to the red terminal, - speaker terminal to the black terminal. When the unit is on monaural operation through BTL, use only the red terminals. Connect the + speaker terminal to the red terminal on the OUTPUT 1 side, - speaker terminal to the red terminal on the OUTPUT 2 side.

5 BAL/UNBAL (balanced/unbalanced) switch

When you set the switch to BAL, the unit feeds in the input signal from the source connected to the XLR type INPUT connector.

When you set the switch to UNBAL, the unit feeds in the input signal from the source connected to the XLR type INPUT connector* or to the phono type INPUT jacks. You can make a stacking connection with another amplifier since these input connectors are in parallel connection.

* In this case, the XLR type INPUT connector accepts unbalanced input (Number 2: HOT).

6 FUSE holder

There is a fuse to prevent damage from excessive current. Current capacity is 8A for the MU-A400 and 4A for the MU-A200. When you replace the fuse, be sure to use one with the same capacity.

7 -AC IN (inlet)

Connect the AC power cord supplied. The unit operates on 220-240V AC, 50/60 Hz.

Rack Mounting

By using the mounting parts on both sides, you can install the unit in an EIA standard 19-inch rack. If you install various pieces of equipment one upon another, remove the unit's bottom support. To remove, pull out the screws of the supports, by using a screwdriver.

Connection Examples

Connection Notes


On power sources

- To avoid damaging the unit or to prevent the circuit breaker from working accidentally:
 - Use an extension cord that can bear 10A current.
 - Do not connect many pieces of equipment to the same AC outlet.


On connecting cables

- The power cord should be connected last. First make sure that the POWER switch is turned off.
- The cable connectors should be fully inserted into the jacks. A loose connection may cause hum and noise.
- Unplug the cord from the wall outlet by grasping the plug. Never take out the plug by pulling on the cord.


Using the Unit as a Monaural Amplifier through BTL



Using the Unit as a Stereo Amplifier



Using the Unit with Internal Stacking Connections



SECTION 2 ADJUSTMENTS

[Preparation]


1. Turn the semi-final resistors from VR601 to VR604 and set at the mechanical center position.
2. The following adjustment must be done a five minutes passed after the power on.

[Offset Adujstment]

1. Connect the multi-voltage meter to the resistor R6011 (or R6012) and minus terminal of C851 at none signal input condition as shown in fig.1.
2. Adjust the semi-final resistor VR603(or VR604) to zero volt.


[Bias Adjustment]

1. Connect the multi-voltage meter to the both side of the resistor R687(or R688) at none signal input condition as shown in fig.2.
2. Adjust the semi-final resistor VR601(or VR602) and set the bias voltage from 2 to 5 mV.




SECTION 3 DIAGRAMS

3-1. BLOCK DIAGRAM




3-2. CIRCUIT BOARD LOCATION




3-3. SEMICONDUCTOR LEAD LAYOUTS (MU-A200/A400 : Common)

M5220P
NJM2904-D




2SA1306B-Y
2SC3298B-Y




2SC3999-L




1SS83




NJM7824FA
RC7812FA




2SA1383
2SC3514




2SD1189




AA3422S




μ PC1237HA



2SA1492-Y
2SC3856M-OPY



RD24FB1




SEL3410G




DTC124ES



1SR139-400



TLR123



2SA1174



2SA953-LA
2SC2002-L




● SEMICONDUCTOR LOCATION

Ref. No	Location
D411	F-4
D412	F-1
D413	E-4
D414	E-1
D415	E-4
D416	F-1
D417	F-4
D418	F-1
D419	F-3
D420	F-2
D421	F-3
D422	F-2
D423	F-3
D424	F-2
D425	F-3
D426	F-2
D427	F-3
D428	F-2
D429	F-3
D430	F-2
D431	E-3
D432	E-2
D433	E-3
D434	E-2
D435	E-3
D436	E-2
D437	E-3
D438	E-2
D439	E-2
D501	B-6
D502	B-4
D503	B-5
D504	B-3
D505	B-6
D506	B-4
D507	B-5
D508	B-3
D805	E-7
D806	E-7
D807	E-6
IC401	E-3
IC402	E-1
IC501	C-5
IC502	B-3
IC503	B-6
IC504	B-4
IC801	E-8
IC802	E-9
Q805	F-7


3-4. PRINTED WIRING BOARDS — PRE AMP SECTION — (MU-A200/A400 : Identical)
(Conductor side)

● Refer to page 9 for Semiconductor Lead Layouts.



Note on Printed Wiring Boards:

- : parts extracted from the component side.
- : parts extracted from the conductor side.






- : fusible resistor.

Les composants identifiés par une marque  sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

- : Signal path.

IC401, 402 (BA683A)



3-6. PRINTED WIRING BOARDS – MAIN AMP SECTION – (MU-A200/A400 : Common) (Conductor side)


- Refer to page 9 for Semiconductor Lead Layouts.

● SEMICONDUCTOR LOCATION. (* : MUA-400)


Ref. No.	Location	Ref. No.	Location
D401	A-3	Q611	B-8
D402	G-3	Q612	F-8
D409	B-2	Q613	B-9
D410	G-3	Q614	F-8
D601	B-6	Q615	C-5
D602	G-6	Q616	E-5
D603	A-6	Q617	C-7
D604	G-6	Q618	E-7
D605	B-7	Q619	C-5
D606	G-8	Q620	E-5
D607	B-7	Q621	C-7
D608	G-7	Q622	E-7
D609	A-9	Q623*	C-3
D610	G-9	Q624*	E-2
D611	A-10	Q625*	C-3
D612	G-10	Q626*	E-2
D613	A-6	Q627	C-3
D614	G-6	Q628	E-3
D615	A-7	Q629	C-3
D616	G-6	Q630	E-3
D617	F-2	Q631	C-4
D618	C-2	Q632	E-4
D619	F-2	Q633	C-4
D620	C-2	Q634	E-4
D621	B-8	Q635*	C-7
D622	G-9	Q636*	E-7
D801	A-8	Q637	C-8
D802	G-7	Q638	E-8
D803	B-9	Q639	C-9
D804	G-8	Q640	E-9
D851	D-7	Q641*	C-9
D852	E-7	Q642*	E-9
IC601	B-4	Q643*	C-10
IC602	G-4	Q644*	E-10
IC605	B-3	Q645*	C-10
IC606	G-3	Q646*	E-10
IC607	A-9	Q647	B-8
IC608	G-9	Q648	G-9
Q401	B-2	Q649	B-8
Q402	G-2	Q650	G-8
Q403	A-3	Q801	A-8
Q404	G-3	Q802	G-7
Q405	A-7	Q803	B-8
Q406	G-7	Q804	G-8
Q601	A-6		
Q602	G-6		
Q603	A-7		
Q604	G-6		
Q605	B-6		
Q606	G-6		
Q607	B-7		
Q608	G-6		
Q609	C-6		
Q610	E-6		

Note on Printed Wiring Boards:

- ○ — : parts extracted from the component side.
- ● — : parts extracted from the conductor side.







Note on Schematic Diagram :

- All capacitors are in μF unless otherwise noted. pF : μF
- All resistors are in Ω and $\frac{1}{4}W$ or less unless otherwise specified.
- : nonflammable resistor.
- : fusible resistor.


Note :
The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.

Note :
Les composants identifiés par une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
- : Signal path.

• IC BLOCK DIAGRAM

IC607, 608 ($\mu PC1237HA$)



● SEMICONDUCTOR LOCATION (* : MUA-400)


Ref. No.	Location	Ref. No.	Location
D401	A-3	Q611	B-8
D402	G-3	Q612	F-8
D409	B-2	Q613	B-9
D410	G-3	Q614	F-8
D601	B-6	Q615	C-5
D602	G-6	Q616	E-5
D603	A-6	Q617	C-7
D604	G-6	Q618	E-7
D605	B-7	Q619	C-5
D606	G-8	Q620	E-5
D607	B-7	Q621	C-7
D608	G-7	Q622	E-7
D609	A-9	Q623*	C-3
D610	G-9	Q624*	E-2
D611	A-10	Q625*	C-3
D612	G-10	Q626*	E-2
D613	A-6	Q627	C-3
D614	G-6	Q628	E-3
D615	A-7	Q629	C-3
D616	G-6	Q630	E-3
D617	F-2	Q631	C-4
D618	C-2	Q632	E-4
D619	F-2	Q633	C-4
D620	C-2	Q634	E-4
D621	B-8	Q635*	C-7
D622	G-9	Q636*	E-7
D801	A-8	Q637	C-8
D802	G-7	Q638	E-8
D803	B-9	Q639	C-9
D804	G-8	Q640	E-9
D851	D-7	Q641*	C-9
D852	E-7	Q642*	E-9
IC601	B-4	Q643*	C-10
IC602	G-4	Q644*	E-10
IC605	B-3	Q645*	C-10
IC606	G-3	Q646*	E-10
IC607	A-9	Q647	B-8
IC608	G-9	Q648	G-9
Q401	B-2	Q649	B-8
Q402	G-2	Q650	G-8
Q403	A-3	Q801	A-8
Q404	G-3	Q802	G-7
Q405	A-7	Q803	B-8
Q406	G-7	Q804	G-8
Q601	A-6		
Q602	G-6		
Q603	A-7		
Q604	G-6		
Q605	B-6		
Q606	G-6		
Q607	B-7		
Q608	G-6		
Q609	C-6		
Q610	E-6		

Note on Printed Wiring Boards:


- : parts extracted from the component side.
- : parts extracted from the conductor side.


3-8. PRINTED WIRING BOARDS – MAIN AMP SECTION – (MU-A200/A400 : Common)
(Conductor side)


● Refer to page 9 for Semiconductor Lead Layouts.



● Refer to page 9 for Semiconductor Lead Layouts.







Note on Schematic Diagram :


- All capacitors are in μF unless otherwise noted. pF: μF 50WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $\frac{1}{4}W$ or less unless otherwise specified.
- : nonflammable resistor.
- : fusible resistor.

Note :
The components identified by mark or dotted line with mark are critical for safety. Replace only with part number specified.

Note :
Les composants identifiés par une marque sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
- : Signal path.

• IC BLOCK DIAGRAM
IC607, 608 ($\mu PC1237HA$)



SECTION 4
EXPLODED VIEWS

NOTE :


- The mechanical parts with no reference number in the exploded views are not supplied.
- Items marked “ * ” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Color indication of Appearance Parts
Example :
KNOB, BALANCE (WHITE)....(RED)
Parts color Cabinet's color
- Hardware (# mark)list is given in the last of this parts list.

The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.


Les composants identifiés par une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

4-1. OUTER EXTERNAL SECTION



Ref.No.	Part No.	Description	Remarks	Ref.No.	Part No.	Description	Remarks
1	2-337-209-01	KNOB, SQUARE(POWER)		* 6	2-338-494-01	(MU-A200)..SHEET, INSULATION(140X75X0.5)	
2	4-864-307-00	RING(FLEXIBLE)		* 7	2-338-496-01	(MU-A400)..	
3	2-338-186-01	KNOB				RUBBER, VIBRATION PROOF(50X50X2)	
* 4	2-338-316-01	(MU-A400)..PLATE, TOP		* 7	2-338-496-11	(MU-A200)..	
* 4	2-338-327-01	(MU-A200)..PLATE, TOP				RUBBER, VIBRATION PROOF(50X50X4)	
				* 8	2-338-328-01	PLATE, BOTTOM	
* 5	2-338-324-01	(MU-A200)..INSULATOR(50X71X0.5)		9	2-335-084-01	FOOT	

4-2. MAIN SECTION




The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No.	Part No.	Description	Remarks	Ref.No.	Part No.	Description	Remarks	Ref.No.	Part No.
* 51	1-642-606-11	PC BOARD, LED		* 61	2-338-331-01	(MU-A400)..HEAT SINK		* 101	2-338-31
52	2-338-499-01	LED SPACER(CYLINDRICAL)		* 61	2-338-335-01	(MU-A200)..HEAT SINK		* 101	2-338-32
53	2-338-500-01	LED SPACER(RECTANGULAR)		* 62	A-4588-484-A	(MU-A400)..MOUNTED PCB, FINAL(1)		* 102	2-338-18
* 54	1-642-602-11	PC BOARD, VR-1		* 62	A-4588-486-A	(MU-A200)..MOUNTED PCB, FINAL(1)		* 102	2-338-22
* 55	1-642-601-11	PC BOARD, VR-2		* 63	A-4588-485-A	(MU-A400)..MOUNTED PCB, FINAL(2)		* 103	2-338-40
* 56	1-642-575-11	PC BOARD, POWER SUPPLY		* 63	A-4588-487-A	(MU-A200)..MOUNTED PCB, FINAL(2)			
* 57	2-338-330-01	(MU-A400)..PANEL(L), SIDE		64	4-879-937-01	SHEET, MICA(SINGLE)			
* 57	2-338-336-01	(MU-A200)..PANEL(L), SIDE		65	2-338-501-01	SHEET, MICA(SERIES)			
* 58	2-338-330-11	(MU-A400)..PANEL(R), SIDE		* 66	1-646-271-11	(MU-A400)..PC BOARD, THERMAL PROTECTOR 1			
* 58	2-338-337-01	(MU-A200)..PANEL(R), SIDE		* 67	2-338-185-01	(MU-A400)..FOOT			
* 59	2-338-495-01	(MU-A400)..		67	2-337-453-01	(MU-A200)..FOOT			
		RUBBER, VIBRATION PROOF(A) (50X120X8)		* 68	1-646-272-11	(MU-A400)..PC BOARD, THERMAL PROTECTOR 2			
* 59	2-338-498-01	(MU-A200)..		 S851	1-571-649-11	SWITCH, PUSH(AC POWER)			
		RUBBER, VIBRATION PROOF(B) (50X75X8)							
* 60	2-338-323-01	REINFORCEMENT(A)							

by
mark
ber
une
ir la
une
ié.

4-2. MAIN SECTION




The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque  sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No.	Part No.	Description	Remarks
* 51	1-642-606-11	PC BOARD, LED	
52	2-338-499-01	LED SPACER(CYLINDRICAL)	
53	2-338-500-01	LED SPACER(RECTANGULAR)	
* 54	1-642-602-11	PC BOARD, VR-1	
* 55	1-642-601-11	PC BOARD, VR-2	
* 56	1-642-575-11	PC BOARD, POWER SUPPLY	
* 57	2-338-330-01 (MU-A400)...	PANEL(L), SIDE	
* 57	2-338-336-01 (MU-A200)...	PANEL(L), SIDE	
* 58	2-338-330-11 (MU-A400)...	PANEL(R), SIDE	
* 58	2-338-337-01 (MU-A200)...	PANEL(R), SIDE	
* 59	2-338-495-01 (MU-A400)...	RUBBER, VIBRATION PROOF(A) (50X120X8)	
* 59	2-338-498-01 (MU-A200)...	RUBBER, VIBRATION PROOF(B) (50X75X8)	
* 60	2-338-323-01	REINFORCEMENT(A)	

Ref.No.	Part No.	Description	Remarks
* 61	2-338-331-01 (MU-A400)...	HEAT SINK	
* 61	2-338-335-01 (MU-A200)...	HEAT SINK	
* 62	A-4588-484-A (MU-A400)...	MOUNTED PCB, FINAL(1)	
* 62	A-4588-486-A (MU-A200)...	MOUNTED PCB, FINAL(1)	
* 63	A-4588-485-A (MU-A400)...	MOUNTED PCB, FINAL(2)	
* 63	A-4588-487-A (MU-A200)...	MOUNTED PCB, FINAL(2)	
64	4-879-937-01	SHEET, MICA(SINGLE)	
65	2-338-501-01	SHEET, MICA(SERIES)	
* 66	1-646-271-11 (MU-A400)...	PC BOARD, THERMAL PROTECTOR 1	
* 67	2-338-185-01 (MU-A400)...	FOOT	
67	2-337-453-01 (MU-A200)...	FOOT	
* 68	1-646-272-11 (MU-A400)...	PC BOARD, THERMAL PROTECTOR 2	
 S851	1-571-649-11	SWITCH, PUSH(AC POWER)	

4-3. FRONT PANEL SECTION




Ref.No.	Part No.	Description	Remarks
* 101	2-338-317-01 (MU-A400)...	PANEL(BASE), FRONT	
* 101	2-338-326-01 (MU-A200)...	PANEL(BASE), FRONT	
* 102	2-338-184-01 (MU-A400)...	HANDLE	
* 102	2-338-222-01 (MU-A200)...	HANDLE	
* 103	2-338-400-01	COVER	

Ref.No.	Part No.	Description	Remarks
104	2-338-339-01 (MU-A400)...	PANEL, FRONT	
104	2-338-339-11 (MU-A200)...	PANEL, FRONT	
* 105	2-337-212-01	ESCUTCHEON(SMALL)	
* 106	2-337-199-01	ESCUTCHEON, LAMP	
* 107	2-337-200-01	ESCUTCHEON, SWITCH	

arks
5X0.5)

4-4. MAIN CHASSIS SECTION




The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No.	Part No.	Description	Remarks	Ref.No.	Part No.	Description	Remarks
* 151	2-338-494-01	(MU-A200).. SHEET, INSULATION(140X75X0.5)		D851	8-719-029-99	DIODE GBPC2504	
* 152	2-335-096-01	PLATE, ELECTRODE, GROUND		D852	8-719-029-99	DIODE GBPC2504	
C851	1-125-424-11	(MU-A400).. ELECT	18000uF 20% 100V	Δ T801	1-450-906-11	(MU-A400).. TRANSFORMER, POWER	
C851	1-125-425-11	(MU-A200).. ELECT	18000uF 20% 71V	Δ T801	1-450-904-11	(MU-A200).. TRANSFORMER, POWER	
C852	1-125-424-11	(MU-A400).. ELECT	18000uF 20% 100V	Δ TM801	*1-537-125-11	TERMINAL BOARD	
C852	1-125-425-11	(MU-A200).. ELECT	18000uF 20% 71V				

4-5. BACK PANEL SECTION



The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref.No.	Part No.	Description	Remarks	Ref.No.	Part No.	Description	Remarks
* 201	X-2335-295-1	(MU-A400).. PANEL ASSY, BACK		Δ CNJ851	*1-580-375-21	INLET 3P (~AC IN)	
* 201	X-2335-296-1	(MU-A200).. PANEL ASSY, BACK		EF851	1-541-974-11	FAN, ELECTRIC	
* 202	2-338-497-01	SPACER, SWITCH		EF852	1-541-974-11	FAN, ELECTRIC	
203	1-533-210-11	HOLDER, FUSE		Δ F851	1-576-258-11	(MU-A400).. FUSE, GLASS TUBE (250V 8A)	
* 204	A-4588-481-A	MOUNTED PCB, INPUT(1)		Δ F851	1-532-350-00	(MU-A200).. FUSE, TIME-LAG (GLASS TUBE) (250V 4A)	
* 205	1-642-604-11	MOUNTED PCB, INPUT(2)		TM851	1-536-961-11	TERMINAL(5-WAY) (OUTPUT 1)	
* 206	1-642-605-11	MOUNTED PCB, INPUT(3)		TM852	1-536-961-11	TERMINAL(5-WAY) (OUTPUT 2)	
207	4-812-134-00	RIVET, NYLON, 3.5(BLK)					

SECTION 5 ELECTRICAL PARTS LIST

FINAL(1)

NOTE :

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- XX, -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms
METAL : Metal-film resistor
METAL OXIDE : Metal oxide-film resistor
F : nonflammable

- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u : μ , for example :
uA..... : μ A....., uPA..... : μ PA.....
uPB..... : μ PB....., uPC..... : μ PC.....
uPD..... : μ PD.....
CAPACITORS
uF : μ F
COILS
uH : μ H

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remarks
*	A-4588-484-A	MOUNTED PCB, FINAL(1) *****	
< CAPACITOR >			
C401	1-124-902-00	ELECT 0.47uF 20% 50V	
C403	1-124-903-11	ELECT 1uF 20% 50V	
C405	1-124-903-11	ELECT 1uF 20% 50V	
C601	1-136-177-00	FILM 1uF 5% 50V	
C603	1-107-202-00	MICA 10PF 5% 500V	
C605	1-107-202-00	MICA 10PF 5% 500V	
C611	1-161-141-00	CERAMIC 0.001uF 10% 50V	
C613	1-161-141-00	CERAMIC 0.001uF 10% 50V	
C615	1-109-621-00	MICA 220PF 1% 500V	
C617	1-109-621-00	MICA 220PF 1% 500V	
C619	1-106-383-00	MYLAR 0.047uF 5% 200V	
C621	1-126-176-11	ELECT 220uF 20% 10V	
C623	1-124-907-11	ELECT 10uF 20% 50V	
C625	1-124-126-00	ELECT 47uF 20% 10V	
C627	1-124-910-11	ELECT 47uF 20% 50V	
C629	1-124-910-11	ELECT 47uF 20% 50V	
C631	1-161-051-00	CERAMIC 0.01uF 10% 50V	
C633	1-124-902-00	ELECT 0.47uF 20% 50V	
C635	1-109-633-00	MICA 470PF 5% 500V	
C637	1-109-620-00	MICA 200PF 5% 500V	
C639	1-124-927-11	ELECT 4.7uF 20% 50V	
C641	1-124-927-11	ELECT 4.7uF 20% 50V	
< DIODE >			
D401	8-719-901-83	DIODE 1SS83	
D409	8-719-901-83	DIODE 1SS83	
D601	8-719-970-02	DIODE 1SR139-400	
D603	8-719-970-02	DIODE 1SR139-400	
D605	8-719-901-83	DIODE 1SS83	

Ref. No.	Part No.	Description	Remarks
D607	8-719-901-83	DIODE 1SS83	
D609	8-719-901-83	DIODE 1SS83	
D611	8-719-901-83	DIODE 1SS83	
D613	8-719-970-02	DIODE 1SR139-400	
D615	8-719-970-02	DIODE 1SR139-400	
D618	8-719-970-02	DIODE 1SR139-400	
D620	8-719-970-02	DIODE 1SR139-400	
D621	8-719-901-83	DIODE 1SS83	
D622	8-719-901-83	DIODE 1SS83	
D801	8-719-160-77	DIODE RD24FB1	
D803	8-719-160-77	DIODE RD24FB1	
< IC >			
IC601	8-759-602-01	IC M5220P	
IC605	8-759-700-42	IC NJM2904D	
IC607	8-759-111-68	IC uPC1237HA	
< COIL >			
L801	1-422-358-11	COIL, AIR-CORE	
< TRANSISTOR >			
Q401	8-729-925-38	TRANSISTOR 2SD1189	
Q403	8-729-900-36	TRANSISTOR DTC124ES	
Q405	8-729-900-36	TRANSISTOR DTC124ES	
Q601	8-729-104-18	TRANSISTOR 2SC3514	
Q603	8-729-104-91	TRANSISTOR 2SA1383	
Q605	8-729-104-91	TRANSISTOR 2SA1383	
Q607	8-729-104-18	TRANSISTOR 2SC3514	
Q609	8-729-925-38	TRANSISTOR 2SD1189	
Q611	8-729-143-40	TRANSISTOR 2SC2002-L	
Q613	8-729-103-62	TRANSISTOR 2SA953-LA	

FINAL(1)

Ref. No.	Part No.	Description	Remarks
Q615	8-729-104-18	TRANSISTOR 2SC3514	
Q617	8-729-104-91	TRANSISTOR 2SA1383	
Q619	8-729-208-72	TRANSISTOR 2SC3298B-Y	
Q621	8-729-208-75	TRANSISTOR 2SA1306B-Y	
Q623	8-729-010-97 (MU-A400)...	TRANSISTOR 2SC3856	
Q625	8-729-303-86 (MU-A400)...	TRANSISTOR 2SA1492-Y	
Q627	8-729-010-97	TRANSISTOR 2SC3856	
Q629	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q631	8-729-010-97	TRANSISTOR 2SC3856	
Q633	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q635	8-729-010-97 (MU-A400)...	TRANSISTOR 2SC3856	
Q637	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q639	8-729-010-97	TRANSISTOR 2SC3856	
Q641	8-729-303-86 (MU-A400)...	TRANSISTOR 2SA1492-Y	
Q643	8-729-010-97 (MU-A400)...	TRANSISTOR 2SC3856	
Q645	8-729-303-86 (MU-A400)...	TRANSISTOR 2SA1492-Y	
Q647	8-729-117-07	TRANSISTOR 2SC3999-L	
Q649	8-729-117-43	TRANSISTOR 2SA1174	
Q801	8-729-104-18	TRANSISTOR 2SC3514	
Q803	8-729-104-91	TRANSISTOR 2SA1383	
< RESISTOR >			
R401	1-249-437-11	CARBON 47K 5% 1/4W	
R403	1-249-408-11	CARBON 180 5% 1/4W	
R405	1-247-903-00	CARBON 1M 5% 1/4W	
R407	1-249-437-11	CARBON 47K 5% 1/4W	
R409	1-247-903-00	CARBON 1M 5% 1/4W	
R411	1-249-433-11	CARBON 22K 5% 1/4W	
R413	1-249-425-11	CARBON 4.7K 5% 1/4W	
R419	1-249-433-11	CARBON 22K 5% 1/4W	
R421	1-249-433-11	CARBON 22K 5% 1/4W	
R423	1-249-429-11	CARBON 10K 5% 1/4W	
R425	1-247-903-00	CARBON 1M 5% 1/4W	
R427	1-249-429-11	CARBON 10K 5% 1/4W	
R429	1-215-865-11	METAL 220 1% 1W	
R431	1-249-429-11	CARBON 10K 5% 1/4W	
R433	1-249-429-11	CARBON 10K 5% 1/4W	
R435	1-247-903-00	CARBON 1M 5% 1/4W	
R437	1-249-437-11	CARBON 47K 5% 1/4W	
R439	1-249-428-11	CARBON 8.2K 5% 1/4W	
R601	1-249-412-11	CARBON 390 5% 1/4W	
R603	1-249-425-11	CARBON 4.7K 5% 1/4W	
R605	1-247-887-00	CARBON 220K 5% 1/4W	
R607	1-249-413-11	CARBON 470 5% 1/4W	
R609	1-216-431-11	METAL 560 1% 1W	
R611	1-215-893-11	METAL OXIDE 1.5K 5% 2W F	
R615	1-249-419-11	CARBON 1.5K 5% 1/4W	
R617	1-249-410-11	CARBON 270 5% 1/4W	
R619	1-249-410-11	CARBON 270 5% 1/4W	

Ref. No.	Part No.	Description	Remarks
R621	1-249-417-11	CARBON 1K 5% 1/4W	
R623	1-215-876-00	METAL OXIDE 15K 5% 1W F	
R625	1-249-393-11	CARBON 10 5% 1/4W	
R627	1-249-393-11	CARBON 10 5% 1/4W	
R629	1-215-876-00	METAL OXIDE 15K 5% 1W F	
R631	1-249-412-11	CARBON 390 5% 1/4W	
R633	1-249-412-11	CARBON 390 5% 1/4W	
R635	1-249-419-11	CARBON 1.5K 5% 1/4W	
R637	1-249-410-11	CARBON 270 5% 1/4W	
R639	1-249-420-11	CARBON 1.8K 5% 1/4W	
R643	1-212-897-00	FUSIBLE 470 5% 1/4W F	
R645	1-212-881-11	FUSIBLE 100 5% 1/4W F	
R647	1-212-881-11	FUSIBLE 100 5% 1/4W F	
R649	1-212-889-00	FUSIBLE 220 5% 1/4W F	
R651	1-217-637-00 (MU-A400)...	FUSIBLE 1 5% 1/4W F	
R653	1-217-637-00 (MU-A400)...	FUSIBLE 1 5% 1/4W F	
R655	1-217-637-00	FUSIBLE 1 5% 1/4W F	
R657	1-217-637-00	FUSIBLE 1 5% 1/4W F	
R659	1-217-637-00	FUSIBLE 1 5% 1/4W F	
R661	1-217-637-00	FUSIBLE 1 5% 1/4W F	
R663	1-217-637-00 (MU-A400)...	FUSIBLE 1 5% 1/4W F	
R665	1-217-637-00	FUSIBLE 1 5% 1/4W F	
R667	1-217-637-00	FUSIBLE 1 5% 1/4W F	
R669	1-217-637-00 (MU-A400)...	FUSIBLE 1 5% 1/4W F	
R671	1-217-637-00 (MU-A400)...	FUSIBLE 1 5% 1/4W F	
R673	1-217-637-00 (MU-A400)...	FUSIBLE 1 5% 1/4W F	
R675	1-249-419-11	CARBON 1.5K 5% 1/4W	
R677	1-249-419-11	CARBON 1.5K 5% 1/4W	
R679	1-249-421-11	CARBON 2.2K 5% 1/4W	
R681	1-249-421-11	CARBON 2.2K 5% 1/4W	
R683	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R685	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R687	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R687	1-217-156-00 (MU-A200)...	RES, METAL PLATE 0.22 5W	
R689	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R689	1-217-156-00 (MU-A200)...	RES, METAL PLATE 0.22 5W	
R691	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R691	1-217-156-00 (MU-A200)...	RES, METAL PLATE 0.22 5W	
R693	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R693	1-217-156-00 (MU-A200)...	RES, METAL PLATE 0.22 5W	
R695	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R697	1-202-959-11 (MU-A400)...	RES, METAL PLATE 0.39 5W	
R697	1-217-156-00 (MU-A200)...	RES, METAL PLATE 0.22 5W	
R801	1-216-455-11	METAL OXIDE 560 5% 2W F	
R803	1-216-439-00	METAL OXIDE 12K 5% 1W F	
R805	1-212-857-00	FUSIBLE 10 5% 1/4W F	
R807	1-216-455-11	METAL OXIDE 560 5% 2W F	
R809	1-216-439-00	METAL OXIDE 12K 5% 1W F	
R811	1-212-857-00	FUSIBLE 10 5% 1/4W F	

When indicating parts by reference number, please include the board.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

FINAL(1)

FINAL(2)

Ref. No.	Part No.	Description	Remarks			
△R6001	1-202-959-11	(MU-A400)..RES, METAL PLATE	0.39	5W		
△R6001	1-217-156-00	(MU-A200)..RES, METAL PLATE	0.22	5W		
△R6003	1-202-959-11	(MU-A400)..RES, METAL PLATE	0.39	5W		
△R6005	1-202-959-11	(MU-A400)..RES, METAL PLATE	0.39	5W		
△R6007	1-202-959-11	(MU-A400)..RES, METAL PLATE	0.39	5W		
△R6009	1-215-880-00	METAL OXIDE	10	5%	2W	F
△R6011	1-215-880-00	METAL OXIDE	10	5%	2W	F
R6013	1-249-441-11	CARBON	100K	5%	1/4W	
R6015	1-249-428-11	CARBON	8.2K	5%	1/4W	
R6017	1-249-438-11	CARBON	56K	5%	1/4W	
R6019	1-249-416-11	CARBON	820	5%	1/4W	
R6023	1-249-441-11	CARBON	100K	5%	1/4W	
R6025	1-249-415-11	CARBON	680	5%	1/4W	
R6027	1-249-441-11	CARBON	100K	5%	1/4W	
R6029	1-249-417-11	CARBON	1K	5%	1/4W	
R6031	1-249-433-11	CARBON	22K	5%	1/4W	
R6033	1-249-437-11	CARBON	47K	5%	1/4W	
R6035	1-249-437-11	CARBON	47K	5%	1/4W	
R6037	1-249-437-11	CARBON	47K	5%	1/4W	
R6039	1-249-429-11	CARBON	10K	5%	1/4W	
< RELAY >						
RL601	1-515-611-11	RELAY, MINI POWER				
< THERMISTOR >						
TH601	1-806-064-11	POSISTOR(THERMAL PROTECT)				
TH603	1-800-427-00	POSISTOR(THERMAL PROTECT)				
< VARIABLE RESISTOR >						
VR601	1-230-530-11	RES, ADJ, METAL GRAZE	100			
VR603	1-230-522-11	RES, ADJ, METAL GRAZE	4.7K			

*	A-4588-485-A	MOUNTED PCB, FINAL(2)				

< CAPACITOR >						
C402	1-124-902-00	ELECT	0.47uF	20%	50V	
C404	1-124-903-11	ELECT	1uF	20%	50V	
C406	1-124-903-11	ELECT	1uF	20%	50V	
C520	1-161-085-00	CERAMIC	4700PF	10%	50V	
C602	1-136-177-00	FILM	1uF	5%	50V	
C604	1-107-202-00	MICA	10PF	5%	500V	
C606	1-107-202-00	MICA	10PF	5%	500V	
C612	1-161-141-00	CERAMIC	0.001uF	10%	50V	
C614	1-161-141-00	CERAMIC	0.001uF	10%	50V	
C616	1-109-621-00	MICA	220PF	1%	500V	
C618	1-109-621-00	MICA	220PF	1%	500V	
C620	1-106-383-00	NYLAR	0.047uF	5%	200V	

Ref. No.	Part No.	Description	Remarks			
C622	1-126-176-11	ELECT	220uF	20%	10V	
C624	1-124-907-11	ELECT	10uF	20%	50V	
C626	1-124-126-00	ELECT	47uF	20%	10V	
C628	1-124-910-11	ELECT	47uF	20%	50V	
C632	1-161-051-00	CERAMIC	0.01uF	10%	50V	
C634	1-124-902-00	ELECT	0.47uF	20%	50V	
C636	1-109-633-00	MICA	470PF	5%	500V	
C638	1-109-620-00	MICA	200PF	5%	500V	
C640	1-124-927-11	ELECT	4.7uF	20%	50V	
C642	1-124-927-11	ELECT	4.7uF	20%	50V	
< DIODE >						
D402	8-719-901-83	DIODE	1SS83			
D410	8-719-901-83	DIODE	1SS83			
D602	8-719-970-02	DIODE	1SR139-400			
D604	8-719-970-02	DIODE	1SR139-400			
D606	8-719-901-83	DIODE	1SS83			
D608	8-719-901-83	DIODE	1SS83			
D610	8-719-901-83	DIODE	1SS83			
D612	8-719-901-83	DIODE	1SS83			
D616	8-719-970-02	DIODE	1SR139-400			
D617	8-719-970-02	DIODE	1SR139-400			
D619	8-719-970-02	DIODE	1SR139-400			
D622	8-719-901-83	DIODE	1SS83			
D802	8-719-160-77	DIODE	RD24FB1			
D804	8-719-160-77	DIODE	RD24FB1			
< IC >						
IC602	8-759-602-01	IC	M5220P			
IC606	8-759-700-42	IC	NJM2904D			
IC608	8-759-111-68	IC	uPC1237HA			
< COIL >						
L602	1-422-358-11	COIL, AIR-CORE				
< TRANSISTOR >						
Q402	8-729-925-38	TRANSISTOR	2SD1189			
Q404	8-729-900-36	TRANSISTOR	DTC124ES			
Q406	8-729-900-36	TRANSISTOR	DTC124ES			
Q602	8-729-104-18	TRANSISTOR	2SC3514			
Q604	8-729-104-91	TRANSISTOR	2SA1383			
Q606	8-729-104-91	TRANSISTOR	2SA1383			
Q608	8-729-104-18	TRANSISTOR	2SC3514			
Q610	8-729-925-38	TRANSISTOR	2SD1189			
Q612	8-729-143-40	TRANSISTOR	2SC2002-L			
Q614	8-729-103-62	TRANSISTOR	2SA953-LA			
Q616	8-729-104-18	TRANSISTOR	2SC3514			
Q618	8-729-104-91	TRANSISTOR	2SA1383			
Q620	8-729-208-72	TRANSISTOR	2SC3298B-Y			

When indicating parts by reference number, please include the board.

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

FINAL(2)

Ref. No.	Part No.	Description	Remarks
Q622	8-729-208-75	TRANSISTOR 2SA1306B-Y	
Q624	8-729-010-97 (MU-A400)..	TRANSISTOR 2SC3856	
Q626	8-729-303-86 (MU-A400)..	TRANSISTOR 2SA1492-Y	
Q628	8-729-010-97	TRANSISTOR 2SC3856	
Q630	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q632	8-729-010-97	TRANSISTOR 2SC3856	
Q634	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q636	8-729-010-97 (MU-A400)..	TRANSISTOR 2SC3856	
Q638	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q640	8-729-010-97	TRANSISTOR 2SC3856	
Q642	8-729-303-86 (MU-A400)..	TRANSISTOR 2SA1492-Y	
Q644	8-729-010-97 (MU-A400)..	TRANSISTOR 2SC3856	
Q646	8-729-303-86 (MU-A400)..	TRANSISTOR 2SA1492-Y	
Q648	8-729-117-07	TRANSISTOR 2SC3999-L	
Q650	8-729-117-43	TRANSISTOR 2SA1174	
Q802	8-729-104-18	TRANSISTOR 2SC3514	
Q804	8-729-104-91	TRANSISTOR 2SA1383	
< RESISTOR >			
R402	1-249-437-11	CARBON 47K 5% 1/4W	
R404	1-249-408-11	CARBON 180 5% 1/4W	
R406	1-247-903-00	CARBON 1M 5% 1/4W	
R408	1-249-437-11	CARBON 47K 5% 1/4W	
R410	1-247-903-00	CARBON 1M 5% 1/4W	
R412	1-249-433-11	CARBON 22K 5% 1/4W	
R414	1-249-425-11	CARBON 4.7K 5% 1/4W	
R420	1-249-433-11	CARBON 22K 5% 1/4W	
R422	1-249-433-11	CARBON 22K 5% 1/4W	
R424	1-249-429-11	CARBON 10K 5% 1/4W	
R426	1-247-903-00	CARBON 1M 5% 1/4W	
R428	1-249-429-11	CARBON 10K 5% 1/4W	
R430	1-215-865-11	METAL 220 1% 1W	
R432	1-249-429-11	CARBON 10K 5% 1/4W	
R434	1-249-429-11	CARBON 10K 5% 1/4W	
R436	1-247-903-00	CARBON 1M 5% 1/4W	
R438	1-249-437-11	CARBON 47K 5% 1/4W	
R440	1-249-428-11	CARBON 8.2K 5% 1/4W	
R602	1-249-412-11	CARBON 390 5% 1/4W	
R604	1-249-425-11	CARBON 4.7K 5% 1/4W	
R606	1-247-887-00	CARBON 220K 5% 1/4W	
R608	1-249-413-11	CARBON 470 5% 1/4W	
R610	1-216-431-11	METAL 560 1% 1W	
△R612	1-215-893-11	METAL OXIDE 1.5K 5% 2W F	
R616	1-249-419-11	CARBON 1.5K 5% 1/4W	
R618	1-249-410-11	CARBON 270 5% 1/4W	
R620	1-249-410-11	CARBON 270 5% 1/4W	
R622	1-249-417-11	CARBON 1K 5% 1/4W	
△R624	1-215-876-00	METAL OXIDE 15K 5% 1W F	
R626	1-249-393-11	CARBON 10 5% 1/4W	

Ref. No.	Part No.	Description	Remarks
R628	1-249-393-11	CARBON 10 5% 1/4W	
△R630	1-215-876-00	METAL OXIDE 15K 5% 1W F	
R632	1-249-412-11	CARBON 390 5% 1/4W	
R634	1-249-412-11	CARBON 390 5% 1/4W	
R636	1-249-419-11	CARBON 1.5K 5% 1/4W	
R638	1-249-410-11	CARBON 270 5% 1/4W	
R640	1-249-420-11	CARBON 1.8K 5% 1/4W	
△R644	1-212-897-00	FUSIBLE 470 5% 1/4W F	
△R646	1-212-881-11	FUSIBLE 100 5% 1/4W F	
△R648	1-212-881-11	FUSIBLE 100 5% 1/4W F	
△R650	1-212-889-00	FUSIBLE 220 5% 1/4W F	
△R652	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R654	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R656	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R658	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R660	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R662	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R664	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R666	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R668	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R670	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R672	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R674	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
R676	1-249-425-11	CARBON 4.7K 5% 1/4W	
R678	1-249-419-11	CARBON 1.5K 5% 1/4W	
R680	1-249-421-11	CARBON 2.2K 5% 1/4W	
R682	1-249-421-11	CARBON 2.2K 5% 1/4W	
△R684	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R686	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R688	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R688	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R690	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R690	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R692	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R692	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R694	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R694	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R696	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R698	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R698	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R802	1-216-455-11	METAL OXIDE 560 5% 2W F	
△R804	1-216-439-00	METAL OXIDE 12K 5% 1W F	
△R806	1-212-857-00	FUSIBLE 10 5% 1/4W F	
△R808	1-216-455-11	METAL OXIDE 560 5% 2W F	
△R810	1-216-439-00	METAL OXIDE 12K 5% 1W F	
△R812	1-212-857-00	FUSIBLE 10 5% 1/4W F	
△R6002	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R6002	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R6004	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	

When indicating parts by reference number, please include the board.

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

FINAL(2)

INPUT(1)

Ref. No.	Part No.	Description	Remarks		
△R6004	1-217-156-00	(MU-A200)...RES, METAL PLATE	0.22	5W	
△R6006	1-202-959-11	(MU-A400)...RES, METAL PLATE	0.39	5W	
△R6008	1-202-959-11	(MU-A400)...RES, METAL PLATE	0.39	5W	
△R6010	1-215-880-11	METAL OXIDE	10	5%	2W F
△R6012	1-215-880-11	METAL OXIDE	10	5%	2W F
R6014	1-249-441-11	CARBON	100K	5%	1/4W
R6016	1-249-428-11	CARBON	8.2K	5%	1/4W
R6018	1-249-438-11	CARBON	56K	5%	1/4W
R6021	1-249-424-11	CARBON	3.9K	5%	1/4W
R6024	1-249-441-11	CARBON	100K	5%	1/4W
R6026	1-249-415-11	CARBON	680	5%	1/4W
R6030	1-249-425-11	CARBON	4.7K	5%	1/4W
R6032	1-249-433-11	CARBON	22K	5%	1/4W
R6034	1-249-437-11	CARBON	47K	5%	1/4W
R6036	1-249-437-11	CARBON	47K	5%	1/4W
R6038	1-249-437-11	CARBON	47K	5%	1/4W
R6040	1-249-429-11	CARBON	10K	5%	1/4W
< RELAY >					
RL602	1-515-611-11	RELAY, MINI POWER			
RL603	1-515-890-11	RELAY			
< THERMISTOR >					
TH602	1-806-064-11	POSISTOR(THERMAL PROTECT)			
TH604	1-800-427-00	POSISTOR(THERMAL PROTECT)			
< VARIABLE RESISTOR >					
VR602	1-230-530-11	RES, ADJ, METAL GRAZE	100		
VR604	1-230-522-11	RES, ADJ, METAL GRAZE	4.7K		

*	A-4588-481-A	MOUNTED-PCB, INPUT(1)			

< CAPACITOR >					
C501	1-130-789-00	FILM	1uF	5%	100V
C502	1-130-789-00	FILM	1uF	5%	100V
C503	1-130-789-00	FILM	1uF	5%	100V
C504	1-130-789-00	FILM	1uF	5%	100V
C505	1-107-169-00	MICA	100PF	5%	500V
C506	1-107-169-00	MICA	100PF	5%	500V
C507	1-107-210-00	MICA	22PF	5%	500V
C508	1-107-210-00	MICA	22PF	5%	500V
C509	1-107-210-00	MICA	22PF	5%	500V
C510	1-107-210-00	MICA	22PF	5%	500V
C511	1-130-789-00	FILM	1uF	5%	100V
C512	1-130-789-00	FILM	1uF	5%	100V
C513	1-130-789-00	FILM	1uF	5%	100V
C514	1-130-789-00	FILM	1uF	5%	100V

Ref. No.	Part No.	Description	Remarks		
C515	1-107-163-00	MICA	47PF	5%	500V
C516	1-107-163-00	MICA	47PF	5%	500V
C517	1-107-163-00	MICA	47PF	5%	500V
C518	1-107-163-00	MICA	47PF	5%	500V
C519	1-161-149-51	CERAMIC	0.0047uF	10%	50V
< CONNECTOR >					
* CN501	1-563-080-11	CONNECTOR (RECEPTACLE) 3P			
		(INPUT 1 BAL STACKING)			
* CN502	1-563-080-11	CONNECTOR (RECEPTACLE) 3P			
		(INPUT 2 BAL STACKING)			
* CN503	1-566-852-11	CONNECTOR (RECEPTACLE) 3P(INPUT 1 BAL)			
* CN504	1-566-852-11	CONNECTOR (RECEPTACLE) 3P(INPUT 2 BAL)			
< DIODE >					
D501	8-719-901-83	DIODE	1SS83		
D502	8-719-901-83	DIODE	1SS83		
D503	8-719-901-83	DIODE	1SS83		
D504	8-719-901-83	DIODE	1SS83		
D505	8-719-901-83	DIODE	1SS83		
D506	8-719-901-83	DIODE	1SS83		
D507	8-719-901-83	DIODE	1SS83		
D508	8-719-901-83	DIODE	1SS83		
< IC >					
IC501	8-759-602-01	IC	M5220P		
IC502	8-759-602-01	IC	M5220P		
IC503	8-759-602-01	IC	M5220P		
IC504	8-759-602-01	IC	M5220P		
< RESISTOR >					
R501	1-247-887-00	CARBON	220K	5%	1/4W
R502	1-247-887-00	CARBON	220K	5%	1/4W
R503	1-247-887-00	CARBON	220K	5%	1/4W
R504	1-247-887-00	CARBON	220K	5%	1/4W
R507	1-249-430-11	CARBON	12K	5%	1/4W
R508	1-249-430-11	CARBON	12K	5%	1/4W
R509	1-249-420-11	CARBON	1.8K	5%	1/4W
R510	1-249-420-11	CARBON	1.8K	5%	1/4W
R511	1-249-420-11	CARBON	1.8K	5%	1/4W
R512	1-249-420-11	CARBON	1.8K	5%	1/4W
R513	1-249-405-11	CARBON	100	5%	1/4W
R514	1-249-405-11	CARBON	100	5%	1/4W
R515	1-249-405-11	CARBON	100	5%	1/4W
R516	1-249-405-11	CARBON	100	5%	1/4W
R517	1-247-895-00	CARBON	470K	5%	1/4W
R518	1-247-895-00	CARBON	470K	5%	1/4W
R519	1-247-895-00	CARBON	470K	5%	1/4W
R520	1-247-895-00	CARBON	470K	5%	1/4W
R521	1-249-420-11	CARBON	1.8K	5%	1/4W

When indicating parts by reference number, please include the board.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

INPUT(1)	INPUT(2)	INPUT(3)	LED
----------	----------	----------	-----

Ref. No.	Part No.	Description	Remarks
R522	1-249-420-11	CARBON	1.8K 5% 1/4W
R523	1-249-420-11	CARBON	1.8K 5% 1/4W
R524	1-249-420-11	CARBON	1.8K 5% 1/4W
R525	1-249-425-11	CARBON	4.7K 5% 1/4W
R526	1-249-425-11	CARBON	4.7K 5% 1/4W
R527	1-249-425-11	CARBON	4.7K 5% 1/4W
R528	1-249-425-11	CARBON	4.7K 5% 1/4W
R529	1-249-425-11	CARBON	4.7K 5% 1/4W
R530	1-249-425-11	CARBON	4.7K 5% 1/4W
R531	1-249-425-11	CARBON	4.7K 5% 1/4W
R532	1-249-425-11	CARBON	4.7K 5% 1/4W
R533	1-249-417-11	CARBON	1K 5% 1/4W
R534	1-249-417-11	CARBON	1K 5% 1/4W
< RELAY >			
RL501	1-515-890-11	RELAY	

*	1-642-604-11	PC BOARD, INPUT 2	

< JACK >			
JK502	1-691-945-11	JACK 2P (INPUT 1 UNBAL)	
< RESISTOR >			
R506	1-247-887-00	CARBON	220K 5% 1/4W
< SWITCH >			
SW502	1-692-127-11	SWITCH, SLIDE (INPUT 1 BAL/UNBAL)	

*	1-642-605-11	PC BOARD, INPUT 3	

< JACK >			
JK501	1-691-945-11	JACK 2P (INPUT 2 UNBAL)	
< RESISTOR >			
R505	1-247-887-00	CARBON	220K 5% 1/4W
< SWITCH >			
SW501	1-692-127-11	SWITCH, SLIDE (INPUT 2 BAL/UNBAL)	
SW503	1-692-129-11	SWITCH, SLIDE (OPERATION)	

Ref. No.	Part No.	Description	Remarks
*	1-642-606-11	PC BOARD, LED	

< CAPACITOR >			
C403	1-124-907-11	ELECT	10uF 20% 50V
C404	1-124-907-11	ELECT	10uF 20% 50V
C405	1-126-101-11	ELECT	100uF 20% 16V
< LED >			
D411	8-719-312-20	LED SEL3410G	(GRN) (CH1 OPERATION)
D412	8-719-312-20	LED SEL3410G	(GRN) (CH2 OPERATION)
D413	8-719-812-31	LED TLR123 (RED)	(CH1 CRIP)
D414	8-719-812-31	LED TLR123 (RED)	(CH2 CRIP)
D415	8-719-812-31	LED TLR123 (RED)	(CH1 HIGH TEMP)
D416	8-719-812-31	LED TLR123 (RED)	(CH2 HIGH TEMP)
D417	8-719-812-31	LED TLR123 (RED)	(CH1 PROTECTION)
D418	8-719-812-31	LED TLR123 (RED)	(CH2 PROTECTION)
D419	8-719-918-96	LED AA3422S (ORG)	(CH1 0.9W -21dB)
D420	8-719-918-96	LED AA3422S (ORG)	(CH2 0.9W -21dB)
D421	8-719-918-96	LED AA3422S (ORG)	(CH1 1.7W -18dB)
D422	8-719-918-96	LED AA3422S (ORG)	(CH2 1.7W -18dB)
D423	8-719-918-96	LED AA3422S (ORG)	(CH1 3.4W -15dB)
D424	8-719-918-96	LED AA3422S (ORG)	(CH2 3.4W -15dB)
D425	8-719-918-96	LED AA3422S (ORG)	(CH1 6.8W -12dB)
D426	8-719-918-96	LED AA3422S (ORG)	(CH2 6.8W -12dB)
D427	8-719-918-96	LED AA3422S (ORG)	(CH1 12.5W -9dB)
D428	8-719-918-96	LED AA3422S (ORG)	(CH2 12.5W -9dB)
D429	8-719-918-96	LED AA3422S (ORG)	(CH1 25W -6dB)
D430	8-719-918-96	LED AA3422S (ORG)	(CH2 25W -6dB)
D431	8-719-918-96	LED AA3422S (ORG)	(CH1 50W -3dB)
D432	8-719-918-96	LED AA3422S (ORG)	(CH2 50W -3dB)
D433	8-719-918-96	LED AA3422S (ORG)	(CH1 100W 0dB)
D434	8-719-918-96	LED AA3422S (ORG)	(CH2 100W 0dB)
D435	8-719-918-96	LED AA3422S (ORG)	(CH1 200W +3dB)
D436	8-719-918-96	LED AA3422S (ORG)	(CH2 200W +3dB)
D437	8-719-812-31	LED TLR123 (RED)	(CH1 400W +6dB)
D438	8-719-812-31	LED TLR123 (RED)	(CH2 400W +6dB)
D439	8-719-312-20	LED SEL3410G (GRN)	(POWER ON)
< IC >			
IC401	8-759-087-35	IC BA683A	
IC402	8-759-087-35	IC BA683A	
< RESISTOR >			
R741	1-249-425-11	CARBON	4.7K 5% 1/4W
R442	1-249-425-11	CARBON	4.7K 5% 1/4W

When indicating parts by reference number, please include the board.

LED

POWER SUPPLY

VR-1

VR-2

THERMAL PROTECTOR 1

THERMAL PROTECTOR 2

Ref. No.	Part No.	Description	Remarks
R445	1-249-428-11	CARBON	8.2K 5% 1/4W
R446	1-249-428-11	CARBON	8.2K 5% 1/4W
R447	1-249-441-11	CARBON	100K 5% 1/4W
R448	1-249-441-11	CARBON	100K 5% 1/4W
R449	1-249-429-11	CARBON	10K 5% 1/4W
R450	1-249-429-11	CARBON	10K 5% 1/4W
R451	1-249-421-11	CARBON	2.2K 5% 1/4W

*	1-642-575-11	PC BOARD, POWER SUPPLY	*****
< CAPACITOR >			
C801	1-124-922-11	ELECT	1000uF 20% 63V
C802	1-124-907-11	ELECT	10uF 20% 50V
C803	1-124-907-11	ELECT	10uF 20% 50V
C805	1-124-443-00	ELECT	100uF 20% 6.3V
< DIODE >			
D805	8-719-970-02	DIODE	1SR139-400
D806	8-719-970-02	DIODE	1SR139-400
D807	8-719-901-83	DIODE	1SS83
< FUSE >			
△F801	1-532-360-XX	FUSE, GLASS TUBE(100V 1A)	
*	1-533-185-11	HOLDER, FUSE	
△F802	1-532-360-XX	FUSE, GLASS TUBE(100V 1A)	
*	1-533-185-11	HOLDER, FUSE	
< IC >			
IC801	8-759-701-83	IC	NJM7824FA
IC802	8-759-982-13	IC	RC7812FA
< TRANSISTOR >			
Q805	8-729-900-36	TRANSISTOR	DTC124ES
< RESISTOR >			
△R813	1-219-211-11	FUSIBLE(TEMPERATURE, 130°C)	1 10% 2.40W
△R814	1-217-160-00	RES, METAL PLATE	1.0 5W
△R815	1-217-160-00	RES, METAL PLATE	1.0 5W
△R816	1-217-160-00	RES, METAL PLATE	1.0 5W
△R817	1-217-160-00	RES, METAL PLATE	1.0 5W
R823	1-249-431-11	CARBON	15K 5% 1/4W
R824	1-249-431-11	CARBON	15K 5% 1/4W
R825	1-249-441-11	CARBON	100K 5% 1/4W
< RELAY >			
△RL801	1-515-891-11	RELAY	

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remarks
*	1-642-602-11	PC BOARD, VR-1	*****
< VARIABLE RESISTOR >			
VR502	1-241-910-11	VARIABLE RESISTOR 10KA (CH1 ATTENUATOR)	*****

*	1-642-601-11	PC BOARD, VR-2	*****
< VARIABLE RESISTOR >			
VR501	1-241-910-11	VARIABLE RESISTOR 10KA (CH2 ATTENUATOR)	*****

*	1-646-271-11	(MU-A400)..PC BOARD, THERMAL PROTECTOR 1	*****
< THERMISTOR >			
TH603	1-880-427-00	POSISTOR(THERMAL PROTECT)	*****

*	1-646-272-11	(MU-A400)..PC BOARD, THERMAL PROTECTOR 2	*****
< THERMISTOR >			
TH604	1-800-427-00	POSISTOR(THERMAL PROTECT)	*****

MISCELLANEOUS			

203	1-533-210-11	HOLDER, FUSE	
C851	1-125-424-11	(MU-A400)..	
		ELECT	18000uF 20% 100V
C851	1-125-425-11	(MU-A200)..	
		ELECT	18000uF 20% 71V
C852	1-125-424-11	(MU-A400)..	
		ELECT	18000uF 20% 100V
C852	1-125-424-11	(MU-A200)..	
		ELECT	18000uF 20% 71V
△*CNJ851	1-580-375-21	INLET 3P (~ AC IN)	
D851	8-719-029-99	DIODE	GBPC2504
D852	8-719-029-99	DIODE	GBPC2504
EF851	1-541-974-11	FAN, ELECTRIC	
EF852	1-541-974-11	FAN, ELECTRIC	
△F851	1-576-258-00	(MU-A400)..FUSE, GLASS TUBE(250V 8A)	
△F851	1-532-350-00	(MU-A200)..FUSE, TIME-LAG (GLASS TUBE)	(250V 4A)
△S851	1-571-649-11	SWITCH, PUSH (AC POWER)	
△T801	1-450-904-11	(MU-A200)..TRANSFORMER, POWER	
△T801	1-450-906-11	(MU-A400)..TRANSFORMER, POWER	

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
* TM801	1-537-125-11	TERMINAL BOARD	
TM851	1-536-961-11	TERMINAL(5-WAY)(OUTPUT 1)	
TM852	1-536-961-11	TERMINAL(5-WAY)(OUTPUT 2)	

ACCESSORIES & PACKING MATERIAL

△ *	1-559-656-11	CORD, POWER	
	2-338-218-12	MANUAL, INSTRUCTION(ENGLISH, FRENCH, GERMAN)	
*	3-704-300-01	BAG(STANDARD), PROTECTION	
△	1-576-258-00	(MU-A400)..FUSE, GLASS TUBE(250V 8A)	
△	1-532-350-00	(MU-A200)..FUSE, TIME-LAG (GLASS TUBE) (250V 4A)	

HARDWARE LIST

#1	7-621-773-95	SCREW +B 2.6X6 (BLK)
#2	7-682-247-04	SCREW +K 3X6
#3	7-682-548-09	SCREW +B 3X8 (BLK)
#4	7-682-549-09	SCREW +B 3X10 (BLK)
#5	7-682-561-04	SCREW +B 4X8
#6	7-682-561-09	SCREW +B 4X8 (BLK)
#7	7-682-565-09	SCREW +B 4X16 (BLK)
#8	7-682-568-09	SCREW +B 4X30 (BLK)
#9	7-682-576-04	(MU-A400)..SCREW +B 5X12
#9	7-682-562-04	(MU-A200)..SCREW +B 4X10
#10	7-682-950-01	SCREW +PSW 3X12
#11	7-685-246-14	SCREW +KTP 3X8, TYPE 2 NON-SLIT
#12	7-685-645-79	SCREW +BVTP 3X6, TYPE 2, IT-3 (BLK)
#13	7-685-646-79	SCREW +BVTP 3X8, TYPE 2, IT-3 (BLK)
#14	7-685-648-79	SCREW +BVTP 3X12, TYPE 2, IT-3 (BLK)
#15	7-685-663-79	SCREW +BVTP 4X16, TYPE 2, IT-3 (BLK)
#16	7-685-903-11	SCREW +PTPWH 3X6 (TYPE 2)
#17	7-682-248-04	(MU-A200)..SCREW +K 3X8
#17	7-685-246-14	(MU-A400)..SCREW +KTP 3X8, TYPE 2 NON-SLIT
#21	7-623-212-22	SW5, TYPE 2
#22	7-623-422-07	LW3, TYPE B
#23	7-684-024-03	N4, TYPE 2
#24	7-684-023-04	(MU-A200)..N3, TYPE 2

When indicating parts by reference number, please include the board.

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Sony Sound Tec Corporation

9-977-904-11


3436

MU-A200/A400


SERVICE MANUAL

BACKUP FILE

AEP Model



MU-A200



MU-A400

SPECIFICATIONS

Channel 2 channels
Input sensitivity 0dBs (100W +100W, 8 ohm load impedance, both channels driven simultaneously)

Indicator

10-point LED level meter
PROTECTION indicator
HIGH TEMP indicator
CLIP indicator
POWER indicator

Power requirements 220 - 240 V AC, 50/60 Hz
Power consumption MU-A400: 805 W
MU-A200: 425 W

Dimensions

MU-A400:
Approx. 482 x 146 x 490 mm
(w/h/d)
(19 x 4 3/4 x 19 3/8 inches)
MU-A200:
Approx. 482 x 102 x 490 mm
(w/h/d)
(19 x 4 1/8 x 19 3/8 inches)

Weight

MU-A400: Approx. 20.5 kg
(45 lbs 2 oz)
MU-A200: Approx. 15 kg
(33 lbs 2 oz)

Accessories supplied

AC power cord (1)
Fuse MU-A400: 8A (1)
MU-A200: 4A (1)

Note

This appliance conforms with EEC Directive 87/308/EEC regarding interference suppression.

Design and specifications are subject to change without notice.

Input	Balanced	Unbalanced
Circuit	Electronic balanced circuit	
Input impedance	More than 33 kilo-ohms (stereo operation) More than 33 kilo-ohms (monaural operation)	
Connector and jack	XLR-3-31 type	XLR-3-31 type Phono type

Item	Stereo	Monaural (BTL)
Output terminal	Screw type binding terminal	
Rated output*	MU-A400	
	260 W + 260 W (8 ohms) 400 W + 400 W (4 ohms) (both channels driven simultaneously)	520 W (16 ohms) 800 W (8 ohms)
	MU-A200	
	130 W + 130 W (8 ohms) 200 W + 200 W (4 ohms) (both channels driven simultaneously)	260 W (16 ohms) 400 W (8 ohms)
Power bandwidth	20 Hz - 20 kHz $\pm$ 0.5 dB	
Damping factor	More than 150 (8 ohms, 1kHz)	—
Harmonic distortion	Less than 0.1 % (8 ohms, at 100 W output)	Less than 0.1 % (8 ohms, at 200 W output)
Channel separation	More than 70 dB (1kHz: 8 ohms load, at rated output)	—
Residual noise	Less than 100 μ V (IHF-A, input terminated)	Less than 200 μ V (IHF-A, input terminated)
Gain (max.)	31 dB	37 dB
Stacking output connector	XLR-3-32 type	

0 dBs= 0.775 V

*1 % harmonic distortion at 1kHz



MICROFILM

PROFESSIONAL
POWER AMPLIFIER
SONY®

TABLE OF CONTENTS

Section	Title	Page
SPECIFICATIONS		1
1. GENERAL		
	Precautions	3
	Dimensions	3
	Location and Function of Controls	4
	Connection Examples	6
2. ADJUSTMENTS		7
3. DIAGRAMS		
3-1.	Block Diagram	8
3-2.	Circuit Board Location	8
3-3.	Semiconductor Lead Layouts	9
3-4.	Printed Wiring Boards – PRE AMP Section – (MU-A200/A400 : Identical)	11
3-5.	Schematic Diagram – PRE AMP Section – (MU-A200/A400 : Identical)	13
3-6.	Printed Wiring Boards – MAIN AMP Section – (MU-A200/A400 : Common)	16
3-7.	Schematic Diagram – MAIN AMP Section – (MU-A200)	19
3-8.	Printed Wiring Boards – MAIN AMP Section – (MU-A200/A400 : Common)	22
3-9.	Schematic Diagram – MAIN AMP Section – (MU-A400)	25
4. EXPLODED VIEWS		
4-1.	Outer External Section	28
4-2.	Main Section	29
4-3.	Front Panel Section	30
4-4.	Main Chassis Section	31
4-5.	Back Panel Section	32
5. ELECTRICAL PARTS LIST		33

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

NOTICE FOR THE CUSTOMERS IN THE UNITED KINGDOM
THIS APPARATUS MUST BE EARTHED

IMPORTANT

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow: Earth

Blue: Neutral

Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows: The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol $\perp$ or coloured green or green-and-yellow.

The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black. The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK $\triangle$ OR DOTTED LINE WITH MARK $\triangle$ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE $\triangle$ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

SECTION 1 GENERAL

This section is extracted from instruction manual.

Precautions

On Installation

Avoid installing or leaving the unit in a location:

- near heat sources such as radiators, airducts or heaters
- subject to direct sunlight
- exposed to rain or moisture
- where it is unventilated
- exposed to excess dust or dirt
- subject to mechanical vibration or shock


On Operation

- Operate the unit only on 220-240 V AC, 50/60 Hz.
- Unplug the unit from the wall outlet when it is not to be used for an extended period of time. To disconnect the cord, pull it out by grasping the plug. Never take out the plug by pulling on the cord.
- Should any solid object or liquid fall into the component, unplug the unit and have it checked by qualified personnel before using it again.
- Clean the cabinet, panel and knobs periodically using a soft cloth moistened with a mild detergent. Never use an abrasive cleanser or chemical solvents as they may mar the finish.

If you have any questions or problems concerning your unit that are not covered in this manual, please consult your nearest Sony dealer.

3


Dimensions



5

Location and Function of Controls

Front Panel



CHANNEL 1 and CHANNEL 2 have the same function.

- 1 CLIP indicator (red)**
Lights when the output wave is distorted. When the indicator lights frequently, the input level is too high or there is a problem in the input channel.
- 2 HIGH TEMP (temperature) indicator (red)**
Lights when the temperature of the heat sink becomes too high. Take a measure to be well ventilated.
- 3 PROTECTION indicator (red)**
Lights when the protection circuit is working. When you turn on the amplifier, the indicator lights but goes off when the unit starts to work steadily.
- 4 OPERATION indicator (green)**
Shows the operation mode set by the position of the OPERATION switch on the rear panel.

- 5 ATTENUATOR knob**
CHANNEL 1 (MONO): Turn this knob to control the channel 1 input level. You can control the input level with this knob when you are using the unit as a monaural amplifier through BTL.
CHANNEL 2: Turn this knob to control the channel 2 input level. When you set the OPERATION switch on the rear panel to MONO, this knob does not function.
- 6 Level meter**
The 10-point LED level meter shows 0dB at 8 ohms load, 100 W output.
- 7 POWER switch and pilot lamp (green)**
Press this switch to turn on the amplifier. The pilot lamp lights when the unit is turned on.


Position of the OPERATION switch	OPERATION Indicator		Operation mode
	CHANNEL 1	CHANNEL 2	
STEREO	Lights	Lights	Stereo
SAME OUT	Lights	Lights	CHANNEL 2 has the same signal as CHANNEL 1.
MONO	Lights	Out	Monaural through BTL

- 8 Ventilation hole**
Two ventilation holes with a fan are located on both sides of the front panel. The holes are covered with a grill and a cover. When the grills become dusty, the fans do not work properly and the HIGH TEMP indicator starts to light frequently. In this case, remove the ventilation hole cover and clean the grill. Unplug the AC power cord before cleaning the grill.


Caution
Do not touch the interior of the unit when you remove the grill.

Notes on the PROTECTION lamp
When does the PROTECTION lamp light?
The PROTECTION lamp lights when the protection circuit functions to protect the speakers and the amplifier by cutting off the output in the following cases:
• when DC (direct current) runs through the OUTPUT connectors because of a malfunction of the amplifier.
• when the radiator located in the amplifier exceeds the normal temperature (the HIGH TEMP indicator lights continuously).
• when the impedance of the speaker is too low, or when the output is terminated.
In these cases, turn off the POWER switch, find the cause and resolve the problem. Then turn on the POWER switch to operate the amplifier.

To remove the ventilation hole cover




To put back the grill and the cover



Location and Function of Controls

Rear Panel



- 1 INPUT(MONO) (input 1, monaural) and STACKING connectors**
Connect outputs of a mixer or preamplifier.
When you are using the unit as a stereo amplifier, these input connectors are for CHANNEL 1. When you set the OPERATION switch to SAME OUT or MONO, these connectors accept monaural input signals.

INPUT connector (XLR-3-31 type): Accepts balanced input when you set the BAL/UNBAL switch to BAL. When you set the switch to UNBAL, the connector accepts unbalanced input (Number 2: HOT).

INPUT jacks (phono type, unbalanced): Accept unbalanced signals when you set the BAL/UNBAL switch to UNBAL. Use one jack for input, another to connect another amplifier for stacking connection.

STACKING connector (XLR-3-32 type): Feeds out the signal which is received from the XLR type INPUT connector. Use this connector to connect another amplifier for stacking connection.

- 2 INPUT (input 2) and STACKING connectors**

Connect outputs of a mixer or preamplifier.
When you are using the unit as a stereo amplifier, these input connectors are for CHANNEL 2. When you set the OPERATION switch to SAME OUT or MONO, these connectors are disconnected.

INPUT connector (XLR-3-31 type): Accepts balanced input when you set the BAL/UNBAL switch to BAL. When you set the switch to UNBAL, the connector accepts unbalanced input (Number 2: HOT).


INPUT jacks (phono type, unbalanced): Accept unbalanced signals when you set the BAL/UNBAL switch to UNBAL. Use one jack for input, another to connect another amplifier for stacking connection.

STACKING connector (XLR-3-32 type): Feeds out the signal which is received from the XLR type INPUT connector. Use this connector to connect another amplifier for stacking connection.

BAL/UNBAL switch	INPUT 1 (MONO) INPUT 2 connectors
BAL	XLR type connector
UNBAL	Phono type jack

XLR-3-12C type

XLR-3-11C type



- 3 OPERATION switch**
Changes the operation mode of the unit as follows.

OPERATION switch	Operation mode
STEREO	Stereo
SAME OUT	Internal stacking operation CHANNEL 2 has the same signal as the CHANNEL 1 input signal.
BTL	Monaural operation through BTL.

Select the position of this switch when the POWER switch is turned off.

- 4 OUTPUT terminals**

Connect speakers. Connect the + speaker terminal to the red terminal, - speaker terminal to the black terminal.

When the unit is on monaural operation through BTL, use only the red terminals. Connect the + speaker terminal to the red terminal on the OUTPUT 1 side, - speaker terminal to the red terminal on the OUTPUT 2 side.

Rack Mounting

By using the mounting parts on both sides, you can install the unit in an EIA standard 19-inch rack.
If you install various pieces of equipment one upon another, remove the unit's bottom support. To remove, pull out the screws of the supports, by using a screwdriver.

- 5 BAL/UNBAL (balanced/unbalanced) switch**
When you set the switch to BAL, the unit feeds in the input signal from the source connected to the XLR type INPUT connector.
When you set the switch to UNBAL, the unit feeds in the input signal from the source connected to the XLR type INPUT connector* or to the phono type INPUT jacks. You can make a stacking connection with another amplifier since these input connectors are in parallel connection.
* In this case, the XLR type INPUT connector accepts unbalanced input (Number 2: HOT).

- 6 FUSE holder**

There is a fuse to prevent damage from excessive current. Current capacity is 8A for the MU-A400 and 4A for the MU-A200. When you replace the fuse, be sure to use one with the same capacity.

- 7 -AC IN (inlet)**

Connect the AC power cord supplied. The unit operates on 220-240V AC, 50/60 Hz.

Connection Examples

Connection Notes


On power sources

- To avoid damaging the unit or to prevent the circuit breaker from working accidentally:
 - Use an extension cord that can bear 10A current.
 - Do not connect many pieces of equipment to the same AC outlet.


On connecting cables

- The power cord should be connected last. First make sure that the POWER switch is turned off.
- The cable connectors should be fully inserted into the jacks. A loose connection may cause hum and noise.
- Unplug the cord from the wall outlet by grasping the plug. Never take out the plug by pulling on the cord.


Using the Unit as a Monaural Amplifier through BTL



Using the Unit as a Stereo Amplifier



Using the Unit with Internal Stacking Connections



SECTION 2 ADJUSTMENTS

[Preparation]


1. Turn the semi-final resistors from VR601 to VR604 and set at the mechanical center position.
2. The following adjustment must be done a five minutes passed after the power on.

[Offset Adujstment]

1. Connect the multi-voltage meter to the resistor R6011 (or R6012) and minus terminal of C851 at none signal input condition as shown in fig.1.
2. Adjust the semi-final resistor VR603(or VR604) to zero volt.


[Bias Adjustment]

1. Connect the multi-voltage meter to the both side of the resistor R687(or R688) at none signal input condition as shown in fig.2.
2. Adjust the semi-final resistor VR601(or VR602) and set the bias voltage from 2 to 5 mV.




SECTION 3 DIAGRAMS

3-1. BLOCK DIAGRAM



3-2. CIRCUIT BOARD LOCATION



FINAL(1)

FINAL(2)

Ref.No.	Part No.	Description	Remarks			
△R6001	1-202-959-11	(MU-A400)...RES, METAL PLATE	0.39	5W		
△R6001	1-217-156-00	(MU-A200)...RES, METAL PLATE	0.22	5W		
△R6003	1-202-959-11	(MU-A400)...RES, METAL PLATE	0.39	5W		
△R6005	1-202-959-11	(MU-A400)...RES, METAL PLATE	0.39	5W		
△R6007	1-202-959-11	(MU-A400)...RES, METAL PLATE	0.39	5W		
△R6009	1-215-880-00	METAL OXIDE	10	5%	2W	F
△R6011	1-215-880-00	METAL OXIDE	10	5%	2W	F
R6013	1-249-441-11	CARBON	100K	5%	1/4W	
R6015	1-249-428-11	CARBON	8.2K	5%	1/4W	
R6017	1-249-438-11	CARBON	56K	5%	1/4W	
R6019	1-249-416-11	CARBON	820	5%	1/4W	
R6023	1-249-441-11	CARBON	100K	5%	1/4W	
R6025	1-249-415-11	CARBON	680	5%	1/4W	
R6027	1-249-441-11	CARBON	100K	5%	1/4W	
R6029	1-249-417-11	CARBON	1K	5%	1/4W	
R6031	1-249-433-11	CARBON	22K	5%	1/4W	
R6033	1-249-437-11	CARBON	47K	5%	1/4W	
R6035	1-249-437-11	CARBON	47K	5%	1/4W	
R6037	1-249-437-11	CARBON	47K	5%	1/4W	
R6039	1-249-429-11	CARBON	10K	5%	1/4W	
< RELAY >						
RL601	1-515-611-11	RELAY, MINI POWER				
< THERMISTOR >						
TH601	1-806-064-11	POSISTOR(THERMAL PROTECT)				
TH603	1-800-427-00	POSISTOR(THERMAL PROTECT)				
< VARIABLE RESISTOR >						
VR601	1-230-530-11	RES, ADJ, METAL GRAZE	100			
VR603	1-230-522-11	RES, ADJ, METAL GRAZE	4.7K			

* A-4588-485-A MOUNTED PCB, FINAL(2)						

< CAPACITOR >						
C402	1-124-902-00	ELECT	0.47uF	20%	50V	
C404	1-124-903-11	ELECT	1uF	20%	50V	
C406	1-124-903-11	ELECT	1uF	20%	50V	
C520	1-161-085-00	CERAMIC	4700PF	10%	50V	
C602	1-136-177-00	FILM	1uF	5%	50V	
C604	1-107-202-00	MICA	10PF	5%	500V	
C606	1-107-202-00	MICA	10PF	5%	500V	
C612	1-161-141-00	CERAMIC	0.001uF	10%	50V	
C614	1-161-141-00	CERAMIC	0.001uF	10%	50V	
C616	1-109-621-00	MICA	220PF	1%	500V	
C618	1-109-621-00	MICA	220PF	1%	500V	
C620	1-106-383-00	MYLAR	0.047uF	5%	200V	

Ref.No.	Part No.	Description	Remarks			
C622	1-126-176-11	ELECT	220uF	20%	10V	
C624	1-124-907-11	ELECT	10uF	20%	50V	
C626	1-124-126-00	ELECT	47uF	20%	10V	
C628	1-124-910-11	ELECT	47uF	20%	50V	
C632	1-161-051-00	CERAMIC	0.01uF	10%	50V	
C634	1-124-902-00	ELECT	0.47uF	20%	50V	
C636	1-109-633-00	MICA	470PF	5%	500V	
C638	1-109-620-00	MICA	200PF	5%	500V	
C640	1-124-927-11	ELECT	4.7uF	20%	50V	
C642	1-124-927-11	ELECT	4.7uF	20%	50V	
< DIODE >						
D402	8-719-901-83	DIODE	1SS83			
D410	8-719-901-83	DIODE	1SS83			
D602	8-719-970-02	DIODE	1SR139-400			
D604	8-719-970-02	DIODE	1SR139-400			
D606	8-719-901-83	DIODE	1SS83			
D608	8-719-901-83	DIODE	1SS83			
D610	8-719-901-83	DIODE	1SS83			
D612	8-719-901-83	DIODE	1SS83			
D616	8-719-970-02	DIODE	1SR139-400			
D617	8-719-970-02	DIODE	1SR139-400			
D619	8-719-970-02	DIODE	1SR139-400			
D622	8-719-901-83	DIODE	1SS83			
D802	8-719-160-77	DIODE	RD24FB1			
D804	8-719-160-77	DIODE	RD24FB1			
< IC >						
IC602	8-759-602-01	IC	M5220P			
IC606	8-759-700-42	IC	NJM2904D			
IC608	8-759-111-68	IC	uPC1237HA			
< COIL >						
L602	1-422-358-11	COIL, AIR-CORE				
< TRANSISTOR >						
Q402	8-729-925-38	TRANSISTOR	2SD1189			
Q404	8-729-900-36	TRANSISTOR	DTC124ES			
Q406	8-729-900-36	TRANSISTOR	DTC124ES			
Q602	8-729-104-18	TRANSISTOR	2SC3514			
Q604	8-729-104-91	TRANSISTOR	2SA1383			
Q606	8-729-104-91	TRANSISTOR	2SA1383			
Q608	8-729-104-18	TRANSISTOR	2SC3514			
Q610	8-729-925-38	TRANSISTOR	2SD1189			
Q612	8-729-143-40	TRANSISTOR	2SC2002-L			
Q614	8-729-103-62	TRANSISTOR	2SA953-LA			
Q616	8-729-104-18	TRANSISTOR	2SC3514			
Q618	8-729-104-91	TRANSISTOR	2SA1383			
Q620	8-729-208-72	TRANSISTOR	2SC3298B-Y			

When indicating parts by reference number, please include the board.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

FINAL(2)

Ref. No.	Part No.	Description	Remarks
Q622	8-729-208-75	TRANSISTOR 2SA1306B-Y	
Q624	8-729-010-97 (MU-A400)..	TRANSISTOR 2SC3856	
Q626	8-729-303-86 (MU-A400)..	TRANSISTOR 2SA1492-Y	
Q628	8-729-010-97	TRANSISTOR 2SC3856	
Q630	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q632	8-729-010-97	TRANSISTOR 2SC3856	
Q634	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q636	8-729-010-97 (MU-A400)..	TRANSISTOR 2SC3856	
Q638	8-729-303-86	TRANSISTOR 2SA1492-Y	
Q640	8-729-010-97	TRANSISTOR 2SC3856	
Q642	8-729-303-86 (MU-A400)..	TRANSISTOR 2SA1492-Y	
Q644	8-729-010-97 (MU-A400)..	TRANSISTOR 2SC3856	
Q646	8-729-303-86 (MU-A400)..	TRANSISTOR 2SA1492-Y	
Q648	8-729-117-07	TRANSISTOR 2SC3999-L	
Q650	8-729-117-43	TRANSISTOR 2SA1174	
Q802	8-729-104-18	TRANSISTOR 2SC3514	
Q804	8-729-104-91	TRANSISTOR 2SA1383	
< RESISTOR >			
R402	1-249-437-11	CARBON 47K 5% 1/4W	
R404	1-249-408-11	CARBON 180 5% 1/4W	
R406	1-247-903-00	CARBON 1M 5% 1/4W	
R408	1-249-437-11	CARBON 47K 5% 1/4W	
R410	1-247-903-00	CARBON 1M 5% 1/4W	
R412	1-249-433-11	CARBON 22K 5% 1/4W	
R414	1-249-425-11	CARBON 4.7K 5% 1/4W	
R420	1-249-433-11	CARBON 22K 5% 1/4W	
R422	1-249-433-11	CARBON 22K 5% 1/4W	
R424	1-249-429-11	CARBON 10K 5% 1/4W	
R426	1-247-903-00	CARBON 1M 5% 1/4W	
R428	1-249-429-11	CARBON 10K 5% 1/4W	
R430	1-215-865-11	METAL 220 1% 1W	
R432	1-249-429-11	CARBON 10K 5% 1/4W	
R434	1-249-429-11	CARBON 10K 5% 1/4W	
R436	1-247-903-00	CARBON 1M 5% 1/4W	
R438	1-249-437-11	CARBON 47K 5% 1/4W	
R440	1-249-428-11	CARBON 8.2K 5% 1/4W	
R602	1-249-412-11	CARBON 390 5% 1/4W	
R604	1-249-425-11	CARBON 4.7K 5% 1/4W	
R606	1-247-887-00	CARBON 220K 5% 1/4W	
R608	1-249-413-11	CARBON 470 5% 1/4W	
R610	1-216-431-11	METAL 560 1% 1W	
△R612	1-215-893-11	METAL OXIDE 1.5K 5% 2W F	
R616	1-249-419-11	CARBON 1.5K 5% 1/4W	
R618	1-249-410-11	CARBON 270 5% 1/4W	
R620	1-249-410-11	CARBON 270 5% 1/4W	
R622	1-249-417-11	CARBON 1K 5% 1/4W	
△R624	1-215-876-00	METAL OXIDE 15K 5% 1W F	
R626	1-249-393-11	CARBON 10 5% 1/4W	

Ref. No.	Part No.	Description	Remarks
R628	1-249-393-11	CARBON 10 5% 1/4W	
△R630	1-215-876-00	METAL OXIDE 15K 5% 1W F	
R632	1-249-412-11	CARBON 390 5% 1/4W	
R634	1-249-412-11	CARBON 390 5% 1/4W	
R636	1-249-419-11	CARBON 1.5K 5% 1/4W	
R638	1-249-410-11	CARBON 270 5% 1/4W	
R640	1-249-420-11	CARBON 1.8K 5% 1/4W	
△R644	1-212-897-00	FUSIBLE 470 5% 1/4W F	
△R646	1-212-881-11	FUSIBLE 100 5% 1/4W F	
△R648	1-212-881-11	FUSIBLE 100 5% 1/4W F	
△R650	1-212-889-00	FUSIBLE 220 5% 1/4W F	
△R652	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R654	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R656	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R658	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R660	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R662	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R664	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R666	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R668	1-217-637-00	FUSIBLE 1 5% 1/4W F	
△R670	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R672	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
△R674	1-217-637-00 (MU-A400)..	FUSIBLE 1 5% 1/4W F	
R676	1-249-425-11	CARBON 4.7K 5% 1/4W	
R678	1-249-419-11	CARBON 1.5K 5% 1/4W	
R680	1-249-421-11	CARBON 2.2K 5% 1/4W	
R682	1-249-421-11	CARBON 2.2K 5% 1/4W	
△R684	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R686	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R688	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R688	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R690	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R690	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R692	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R692	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R694	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R694	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R696	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R698	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R698	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R802	1-216-455-11	METAL OXIDE 560 5% 2W F	
△R804	1-216-439-00	METAL OXIDE 12K 5% 1W F	
△R806	1-212-857-00	FUSIBLE 10 5% 1/4W F	
△R808	1-216-455-11	METAL OXIDE 560 5% 2W F	
△R810	1-216-439-00	METAL OXIDE 12K 5% 1W F	
△R812	1-212-857-00	FUSIBLE 10 5% 1/4W F	
△R6002	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	
△R6002	1-217-156-00 (MU-A200)..	RES, METAL PLATE 0.22 5W	
△R6004	1-202-959-11 (MU-A400)..	RES, METAL PLATE 0.39 5W	

When indicating parts by reference number, please include the board.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

FINAL(2)

INPUT(1)

Ref. No.	Part No.	Description	Remarks
△R6004	1-217-156-00	(MU-A200)... RES, METAL PLATE	0.22 5W
△R6006	1-202-959-11	(MU-A400)... RES, METAL PLATE	0.39 5W
△R6008	1-202-959-11	(MU-A400)... RES, METAL PLATE	0.39 5W
△R6010	1-215-880-11	METAL OXIDE	10 5% 2W F
△R6012	1-215-880-11	METAL OXIDE	10 5% 2W F
R6014	1-249-441-11	CARBON	100K 5% 1/4W
R6016	1-249-428-11	CARBON	8.2K 5% 1/4W
R6018	1-249-438-11	CARBON	56K 5% 1/4W
R6021	1-249-424-11	CARBON	3.9K 5% 1/4W
R6024	1-249-441-11	CARBON	100K 5% 1/4W
R6026	1-249-415-11	CARBON	680 5% 1/4W
R6030	1-249-425-11	CARBON	4.7K 5% 1/4W
R6032	1-249-433-11	CARBON	22K 5% 1/4W
R6034	1-249-437-11	CARBON	47K 5% 1/4W
R6036	1-249-437-11	CARBON	47K 5% 1/4W
R6038	1-249-437-11	CARBON	47K 5% 1/4W
R6040	1-249-429-11	CARBON	10K 5% 1/4W
< RELAY >			
RL602	1-515-611-11	RELAY, MINI POWER	
RL603	1-515-890-11	RELAY	
< THERMISTOR >			
TH602	1-806-064-11	POSISTOR(THERMAL PROTECT)	
TH604	1-800-427-00	POSISTOR(THERMAL PROTECT)	
< VARIABLE RESISTOR >			
VR602	1-230-530-11	RES, ADJ, METAL GRAZE	100
VR604	1-230-522-11	RES, ADJ, METAL GRAZE	4.7K

*	A-4588-481-A	MOUNTED PCB, INPUT(1)	

< CAPACITOR >			
C501	1-130-789-00	FILM	1uF 5% 100V
C502	1-130-789-00	FILM	1uF 5% 100V
C503	1-130-789-00	FILM	1uF 5% 100V
C504	1-130-789-00	FILM	1uF 5% 100V
C505	1-107-169-00	MICA	100PF 5% 500V
C506	1-107-169-00	MICA	100PF 5% 500V
C507	1-107-210-00	MICA	22PF 5% 500V
C508	1-107-210-00	MICA	22PF 5% 500V
C509	1-107-210-00	MICA	22PF 5% 500V
C510	1-107-210-00	MICA	22PF 5% 500V
C511	1-130-789-00	FILM	1uF 5% 100V
C512	1-130-789-00	FILM	1uF 5% 100V
C513	1-130-789-00	FILM	1uF 5% 100V
C514	1-130-789-00	FILM	1uF 5% 100V

Ref. No.	Part No.	Description	Remarks
C515	1-107-163-00	MICA	47PF 5% 500V
C516	1-107-163-00	MICA	47PF 5% 500V
C517	1-107-163-00	MICA	47PF 5% 500V
C518	1-107-163-00	MICA	47PF 5% 500V
C519	1-161-149-51	CERAMIC	0.0047uF 10% 50V
< CONNECTOR >			
* CN501	1-563-080-11	CONNECTOR (RECEPTACLE) 3P	(INPUT 1 BAL STACKING)
* CN502	1-563-080-11	CONNECTOR (RECEPTACLE) 3P	(INPUT 2 BAL STACKING)
* CN503	1-566-852-11	CONNECTOR (RECEPTACLE) 3P	(INPUT 1 BAL)
* CN504	1-566-852-11	CONNECTOR (RECEPTACLE) 3P	(INPUT 2 BAL)
< DIODE >			
D501	8-719-901-83	DIODE	1SS83
D502	8-719-901-83	DIODE	1SS83
D503	8-719-901-83	DIODE	1SS83
D504	8-719-901-83	DIODE	1SS83
D505	8-719-901-83	DIODE	1SS83
D506	8-719-901-83	DIODE	1SS83
D507	8-719-901-83	DIODE	1SS83
D508	8-719-901-83	DIODE	1SS83
< IC >			
IC501	8-759-602-01	IC	M5220P
IC502	8-759-602-01	IC	M5220P
IC503	8-759-602-01	IC	M5220P
IC504	8-759-602-01	IC	M5220P
< RESISTOR >			
R501	1-247-887-00	CARBON	220K 5% 1/4W
R502	1-247-887-00	CARBON	220K 5% 1/4W
R503	1-247-887-00	CARBON	220K 5% 1/4W
R504	1-247-887-00	CARBON	220K 5% 1/4W
R507	1-249-430-11	CARBON	12K 5% 1/4W
R508	1-249-430-11	CARBON	12K 5% 1/4W
R509	1-249-420-11	CARBON	1.8K 5% 1/4W
R510	1-249-420-11	CARBON	1.8K 5% 1/4W
R511	1-249-420-11	CARBON	1.8K 5% 1/4W
R512	1-249-420-11	CARBON	1.8K 5% 1/4W
R513	1-249-405-11	CARBON	100 5% 1/4W
R514	1-249-405-11	CARBON	100 5% 1/4W
R515	1-249-405-11	CARBON	100 5% 1/4W
R516	1-249-405-11	CARBON	100 5% 1/4W
R517	1-247-895-00	CARBON	470K 5% 1/4W
R518	1-247-895-00	CARBON	470K 5% 1/4W
R519	1-247-895-00	CARBON	470K 5% 1/4W
R520	1-247-895-00	CARBON	470K 5% 1/4W
R521	1-249-420-11	CARBON	1.8K 5% 1/4W

When indicating parts by reference number, please include the board.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

INPUT(1)

INPUT(2)

INPUT(3)

LED

Ref.No.	Part No.	Description	Remarks
R522	1-249-420-11	CARBON	1.8K 5% 1/4W
R523	1-249-420-11	CARBON	1.8K 5% 1/4W
R524	1-249-420-11	CARBON	1.8K 5% 1/4W
R525	1-249-425-11	CARBON	4.7K 5% 1/4W
R526	1-249-425-11	CARBON	4.7K 5% 1/4W
R527	1-249-425-11	CARBON	4.7K 5% 1/4W
R528	1-249-425-11	CARBON	4.7K 5% 1/4W
R529	1-249-425-11	CARBON	4.7K 5% 1/4W
R530	1-249-425-11	CARBON	4.7K 5% 1/4W
R531	1-249-425-11	CARBON	4.7K 5% 1/4W
R532	1-249-425-11	CARBON	4.7K 5% 1/4W
R533	1-249-417-11	CARBON	1K 5% 1/4W
R534	1-249-417-11	CARBON	1K 5% 1/4W

< RELAY >

RL501 1-515-890-11 RELAY

* 1-642-604-11 PC BOARD, INPUT 2

< JACK >

JK502 1-691-945-11 JACK 2P (INPUT 1 UNBAL)

< RESISTOR >

R506 1-247-887-00 CARBON 220K 5% 1/4W

< SWITCH >

SW502 1-692-127-11 SWITCH, SLIDE (INPUT 1 BAL/UNBAL)

* 1-642-605-11 PC BOARD, INPUT 3

< JACK >

JK501 1-691-945-11 JACK 2P (INPUT 2 UNBAL)

< RESISTOR >

R505 1-247-887-00 CARBON 220K 5% 1/4W

< SWITCH >

SW501 1-692-127-11 SWITCH, SLIDE (INPUT 2 BAL/UNBAL)

SW503 1-692-129-11 SWITCH, SLIDE (OPERATION)

Ref.No.	Part No.	Description	Remarks
*	1-642-606-11	PC BOARD, LED	*****
		< CAPACITOR >	
C403	1-124-907-11	ELECT 10uF	20% 50V
C404	1-124-907-11	ELECT 10uF	20% 50V
C405	1-126-101-11	ELECT 100uF	20% 16V
		< LED >	
D411	8-719-312-20	LED SEL3410G	(GRN) (CH1 OPERATION)
D412	8-719-312-20	LED SEL3410G	(GRN) (CH2 OPERATION)
D413	8-719-812-31	LED TLR123 (RED)	(CH1 CRIP)
D414	8-719-812-31	LED TLR123 (RED)	(CH2 CRIP)
D415	8-719-812-31	LED TLR123 (RED)	(CH1 HIGH TEMP)
D416	8-719-812-31	LED TLR123 (RED)	(CH2 HIGH TEMP)
D417	8-719-812-31	LED TLR123 (RED)	(CH1 PROTECTION)
D418	8-719-812-31	LED TLR123 (RED)	(CH2 PROTECTION)
D419	8-719-918-96	LED AA3422S (ORG)	(CH1 0.9W -21dB)
D420	8-719-918-96	LED AA3422S (ORG)	(CH2 0.9W -21dB)
D421	8-719-918-96	LED AA3422S (ORG)	(CH1 1.7W -18dB)
D422	8-719-918-96	LED AA3422S (ORG)	(CH2 1.7W -18dB)
D423	8-719-918-96	LED AA3422S (ORG)	(CH1 3.4W -15dB)
D424	8-719-918-96	LED AA3422S (ORG)	(CH2 3.4W -15dB)
D425	8-719-918-96	LED AA3422S (ORG)	(CH1 6.8W -12dB)
D426	8-719-918-96	LED AA3422S (ORG)	(CH2 6.8W -12dB)
D427	8-719-918-96	LED AA3422S (ORG)	(CH1 12.5W -9dB)
D428	8-719-918-96	LED AA3422S (ORG)	(CH2 12.5W -9dB)
D429	8-719-918-96	LED AA3422S (ORG)	(CH1 25W -6dB)
D430	8-719-918-96	LED AA3422S (ORG)	(CH2 25W -6dB)
D431	8-719-918-96	LED AA3422S (ORG)	(CH1 50W -3dB)
D432	8-719-918-96	LED AA3422S (ORG)	(CH2 50W -3dB)
D433	8-719-918-96	LED AA3422S (ORG)	(CH1 100W 0dB)
D434	8-719-918-96	LED AA3422S (ORG)	(CH2 100W 0dB)
D435	8-719-918-96	LED AA3422S (ORG)	(CH1 200W +3dB)
D436	8-719-918-96	LED AA3422S (ORG)	(CH2 200W +3dB)
D437	8-719-812-31	LED TLR123 (RED)	(CH1 400W +6dB)
D438	8-719-812-31	LED TLR123 (RED)	(CH2 400W +6dB)
D439	8-719-312-20	LED SEL3410G (GRN)	(POWER ON)
		< IC >	
IC401	8-759-087-35	IC BA683A	
IC402	8-759-087-35	IC BA683A	
		< RESISTOR >	
R741	1-249-425-11	CARBON 4.7K 5%	1/4W
R442	1-249-425-11	CARBON 4.7K 5%	1/4W

When indicating parts by reference number, please include the board.

LED

POWER SUPPLY

VR-1

VR-2

THERMAL PROTECTOR 1

THERMAL PROTECTOR 2

Ref. No.	Part No.	Description	Remarks
R445	1-249-428-11	CARBON	8.2K 5% 1/4W
R446	1-249-428-11	CARBON	8.2K 5% 1/4W
R447	1-249-441-11	CARBON	100K 5% 1/4W
R448	1-249-441-11	CARBON	100K 5% 1/4W
R449	1-249-429-11	CARBON	10K 5% 1/4W
R450	1-249-429-11	CARBON	10K 5% 1/4W
R451	1-249-421-11	CARBON	2.2K 5% 1/4W

*	1-642-575-11	PC BOARD, POWER SUPPLY	*****
< CAPACITOR >			
C801	1-124-922-11	ELECT	1000uF 20% 63V
C802	1-124-907-11	ELECT	10uF 20% 50V
C803	1-124-907-11	ELECT	10uF 20% 50V
C805	1-124-443-00	ELECT	100uF 20% 6.3V
< DIODE >			
D805	8-719-970-02	DIODE	1SR139-400
D806	8-719-970-02	DIODE	1SR139-400
D807	8-719-901-83	DIODE	1SS83
< FUSE >			
△F801	1-532-360-XX	FUSE, GLASS TUBE(100V 1A)	
*	1-533-185-11	HOLDER, FUSE	
△F802	1-532-360-XX	FUSE, GLASS TUBE(100V 1A)	
*	1-533-185-11	HOLDER, FUSE	
< IC >			
IC801	8-759-701-83	IC	NJM7824FA
IC802	8-759-982-13	IC	RC7812FA
< TRANSISTOR >			
Q805	8-729-900-36	TRANSISTOR	DTC124ES
< RESISTOR >			
△R813	1-219-211-11	FUSIBLE(TEMPERATURE, 130°C)	1 10% 2.40W
△R814	1-217-160-00	RES, METAL PLATE	1.0 5W
△R815	1-217-160-00	RES, METAL PLATE	1.0 5W
△R816	1-217-160-00	RES, METAL PLATE	1.0 5W
△R817	1-217-160-00	RES, METAL PLATE	1.0 5W
R823	1-249-431-11	CARBON	15K 5% 1/4W
R824	1-249-431-11	CARBON	15K 5% 1/4W
R825	1-249-441-11	CARBON	100K 5% 1/4W
< RELAY >			
△RL801	1-515-891-11	RELAY	

Ref. No.	Part No.	Description	Remarks
*	1-642-602-11	PC BOARD, VR-1	*****
< VARIABLE RESISTOR >			
VR502	1-241-910-11	VARIABLE RESISTOR 10KA (CH1 ATTENUATOR)	*****
*	1-642-601-11	PC BOARD, VR-2	*****
< VARIABLE RESISTOR >			
VR501	1-241-910-11	VARIABLE RESISTOR 10KA (CH2 ATTENUATOR)	*****
*	1-646-271-11	(MU-A400)..PC BOARD, THERMAL PROTECTOR 1	*****
< THERMISTOR >			
TH603	1-880-427-00	POSISTOR(THERMAL PROTECT)	*****
*	1-646-272-11	(MU-A400)..PC BOARD, THERMAL PROTECTOR 2	*****
< THERMISTOR >			
TH604	1-800-427-00	POSISTOR(THERMAL PROTECT)	*****
MISCELLANEOUS			

203	1-533-210-11	HOLDER, FUSE	
C851	1-125-424-11	(MU-A400)..	
		ELECT	18000uF 20% 100V
C851	1-125-425-11	(MU-A200)..	
		ELECT	18000uF 20% 71V
C852	1-125-424-11	(MU-A400)..	
		ELECT	18000uF 20% 100V
C852	1-125-424-11	(MU-A200)..	
		ELECT	18000uF 20% 71V
△*CNJ851	1-580-375-21	INLET 3P (~ AC IN)	
D851	8-719-029-99	DIODE	GBPC2504
D852	8-719-029-99	DIODE	GBPC2504
EF851	1-541-974-11	FAN, ELECTRIC	
EF852	1-541-974-11	FAN, ELECTRIC	
△F851	1-576-258-00	(MU-A400)..FUSE, GLASS TUBE(250V 8A)	
△F851	1-532-350-00	(MU-A200)..FUSE, TIME-LAG (GLASS TUBE)	(250V 4A)
△S851	1-571-649-11	SWITCH, PUSH (AC POWER)	
△T801	1-450-904-11	(MU-A200)..TRANSFORMER, POWER	
△T801	1-450-906-11	(MU-A400)..TRANSFORMER, POWER	

When indicating parts by reference number, please include the board.

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque Δ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remarks
* TM801	1-537-125-11	TERMINAL BOARD	
TM851	1-536-961-11	TERMINAL(5-WAY)(OUTPUT 1)	
TM852	1-536-961-11	TERMINAL(5-WAY)(OUTPUT 2)	

ACCESSORIES & PACKING MATERIAL

△*	1-559-656-11	CORD, POWER	
	2-338-218-12	MANUAL, INSTRUCTION(ENGLISH, FRENCH, GERMAN)	
*	3-704-300-01	BAG(STANDARD), PROTECTION	
△	1-576-258-00	(MU-A400)..FUSE, GLASS TUBE(250V 8A)	
△	1-532-350-00	(MU-A200)..FUSE, TIME-LAG (GLASS TUBE) (250V 4A)	

HARDWARE LIST

#1	7-621-773-95	SCREW +B 2.6X6 (BLK)
#2	7-682-247-04	SCREW +K 3X6
#3	7-682-548-09	SCREW +B 3X8 (BLK)
#4	7-682-549-09	SCREW +B 3X10 (BLK)
#5	7-682-561-04	SCREW +B 4X8
#6	7-682-561-09	SCREW +B 4X8 (BLK)
#7	7-682-565-09	SCREW +B 4X16 (BLK)
#8	7-682-568-09	SCREW +B 4X30 (BLK)
#9	7-682-576-04	(MU-A400)..SCREW +B 5X12
#9	7-682-562-04	(MU-A200)..SCREW +B 4X10
#10	7-682-950-01	SCREW +PSW 3X12
#11	7-685-246-14	SCREW +KTP 3X8, TYPE 2 NON-SLIT
#12	7-685-645-79	SCREW +BVTP 3X6, TYPE 2, IT-3 (BLK)
#13	7-685-646-79	SCREW +BVTP 3X8, TYPE 2, IT-3 (BLK)
#14	7-685-648-79	SCREW +BVTP 3X12, TYPE 2, IT-3 (BLK)
#15	7-685-663-79	SCREW +BVTP 4X16, TYPE 2, IT-3 (BLK)
#16	7-685-903-11	SCREW +PTPWH 3X6 (TYPE 2)
#17	7-682-248-04	(MU-A200)..SCREW +K 3X8
#17	7-685-246-14	(MU-A400)..SCREW +KTP 3X8, TYPE 2 NON-SLIT
#21	7-623-212-22	SW5, TYPE 2
#22	7-623-422-07	LW3, TYPE B
#23	7-684-024-03	N4, TYPE 2
#24	7-684-023-04	(MU-A200)..N3, TYPE 2

When indicating parts by reference number, please include the board.

The components identified by mark △ or dotted line with mark △ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque △ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.